

HyDraw[®] V700

circuit design software for Microsoft Visio



VEST, Inc. 3250 W, Big Beaver Road, Suite 440, Troy, MI 48084 USA

Tel: 01 248 649 9550 Email: sales@VESTusa.com Visit: www.VESTusa.com

HyDraw® V700 Software Product License Agreement

Notice: Read this before installing the software.

Carefully read the terms and conditions of this agreement before opening the product package. Opening the package indicates your acceptance of these terms and conditions. If you do not agree with the terms and conditions of this Agreement, promptly return the package unopened to the place where you obtained it.

Definitions

The Software Product is licensed (not sold) to you. The Software product includes all copies of the Software Product and its related supporting materials.

License

VEST, Inc. (we, our, us) grants you a personal, non-transferable, and non-exclusive license to use the Software Product in the specified quantity only.

You may not:

1. distribute, sublicense or copy any portion of the Licensed Software product;
2. modify or prepare derivative works from the Licensed Software Product;
3. transmit the Licensed Software product electronically by any means; or
4. Use the Licensed Software product in multiple computer or multiple user arrangements unless that use is covered by individual license for each computer or user.

You agree that the Licensed Software product belongs to us and you agree to keep confidential and use your best efforts to prevent and protect the contents of the Licensed Software Product from unauthorized disclosure.

Limited

1. For 90 days from the date of shipment, we warrant that the media (for example, CD) on which the Licensed Software Product is contained will be free from defects in materials and workmanship. The warranty does not cover damage caused by viruses, improper use or neglect.

We do not warrant the contents of the Licensed Software Product (it is furnished "AS IS" and without warranty as to the performance or results you may obtain by using the Licensed Software Product) or that it will be error free.

2. You assume the entire risk as to the results and performance of the Licensed Software Product.

To get media warranty service during the 90-day warranty period, you may return the Product (postage paid) with a description of the problem to the place where you obtained it. The defective media on which the Licensed Software Product is contained will be replaced at no additional charge to you.

3. If you do not receive media that is free from defects in materials and workmanship during the 90-day warranty period, you will receive a refund or credit to your account for the amount you paid for the Licensed Software Product returned.

Disclaimer of Warranty

YOU UNDERSTAND AND AGREE AS FOLLOWS:

1. Warranties in this agreement replace all other warranties, express or implied, including any warranties of merchantability or fitness for a particular purpose. We disclaim and exclude all other warranties.
2. We will not be liable for any loss or damage caused by delay in furnishing a Licensed Software Product or any other performance under this Agreement.
3. Our entire liability and your exclusive remedies for our liability of any kind (including liability for negligence except liability for personal injury caused solely by our negligence) for the Licensed Software Product covered by the Agreement and all other performance or non-performance by us under or related to this Agreement are limited to the remedies specified by this Agreement.
4. In no event will our liability of any kind include any special incidental or consequential damages, even if we have knowledge of the potential loss or damage.
5. Special notice to consumers: some states do not allow the exclusion of implied warranties so the above exclusion may not apply to you. The warranty gives you special legal rights, and you may also have other rights, which vary from state to state.

Termination

This Agreement is effective until terminated. You may terminate it any time by destroying the Licensed Software Product. It will also terminate if you do not comply with any term or condition of this Agreement. You agree upon termination to destroy the Licensed Software Product.

General

You are responsible for installation, management and operation of the Licensed Software Product.

1. Introduction 2
2. Support 4

Workspace 5

3. HyDraw Startup 6
4. HyDraw V700 Ribbon Menu 7
5. HyDraw Library Explorer 8
6. HyDraw Property Manager 11
7. HyDraw Options 14

Inserting Symbols 30

8. Inserting Symbol 31
9. Inserting External Port 33
10. Inserting Gauge Port 37
11. Searching Components 38
12. Searching Sub-systems 44
13. Inserting from Parts List 48
14. Inserting from DC Valve Configurator 50
15. Inserting Envelope 53

Making Connections 54

16. Inserting Connection 55
17. Connecting Lines, Ports, and Symbols 56
18. Fetching Pipe and Tube Data from Library 58
19. Inserting Terminators 59
20. Inserting Interruption Point 60
21. Inserting Connection Point 61

Specifying Properties 62

22. Selected Item Properties 63
23. System Properties 71
24. Copying Properties 72
25. Refreshing Properties 73
26. Updating Property List 74
27. ERP Interface 75

Modifying Symbols 76

28. Aligning Symbols 77
29. Rotating Symbols 78
30. Flipping Symbols 79
31. Aligning Symbol Ports 80
32. Aligning System Port Names 81
33. Editing Port Name 82
34. Editing in Place 83
35. Editing Solenoid Information 84
36. Changing Text Height 85
37. Rotating Property Text 86
38. Unlocking Position 87
39. Unlocking Size 88
40. Relocating Symbol 89
41. Constraining/Unconstraining Symbols 90
42. Stacking Symbols 91
43. Reassigning Item ID 92
44. Updating Balloons 93

Parts List and more 94

45. Creating and Inserting Parts List 95
46. Creating and Inserting Ports List 99
47. Creating and Inserting Net List 101
48. Creating and Inserting Solenoid Actuation Chart 102

Shrink Wrap 103

49. Showing/Hiding Port Names 104
50. Display Settings 105
51. Purging Price Data 106
52. Purging Properties 107
53. Display Format 109

Collating Files 110

54. Collating Documents 111
55. Collating CAD Files 112

Manifold Quote 113

56. Manifold Quote 114

MDTools Interface 115

57. Exporting To MDTools 116

Using QuickManifolds.com 117

58. Introduction to QuickManifolds 118
59. Go To QuickManifolds.com 119
60. Submitting Circuit to QuickManifolds 120
61. Checking Design Status 129
62. QuickManifolds Viewer 131
63. Purging QuickManifolds Data 132

Migrating Drawings 133

64. Saving As DWG 134

Calculator 137

65. Unit Converter 138

Installation & Setup 139

66. HyDraw V700 Installation 140
67. Submitting Authorization Request 142
68. Authorizing HyDraw V700 143
69. Transferring Standalone License 144
70. Using and Borrowing Network License 146
71. Library Network Configuration 147
72. Setup Online Services (FPT & QM) 148
73. Configure ERPServicesConfiguration.xml 151

1. Introduction

Welcome to VEST HyDraw® V700

Create accurate, error free, professionally drawn hydraulic circuits, parts lists, and quotations quickly and easily.

Drag-and-drop 'smart' symbols into a drawing with point-and click component selection. The 'smart' connection lines snap to ports and self-route with jumpers.


Auto BOM generation ensures accuracy of your Bill of Materials. Easily insert it into the circuit drawing, or export it to Microsoft Excel.

Get started with over 7,000 ISO 1219-1 compliant symbols covering both industrial and mobile hydraulics. 'Remember' your data and rules using HyDraw's custom database. Ensure up-to-date pricing of components by linking your ERP data to HyDraw.

HyDraw works seamlessly within Microsoft Visio. Circuit design data can be easily ported to downstream manifold design and CAM systems.

HyDraw can access manufacturer component data from FluidPowerTools.com, a fee based service from VEST. Also, submit your circuit to QuickManifolds.com for 'instant' manifold design.

Use **HyDraw** and ensure your competitive edge.



HyDraw® V700 drawing area with Ribbon menu, HyDraw Library Explorer, and HyDraw Property Manager

HyDraw[®] V700 is easy to use. It works seamlessly within the Microsoft Office Visio environment with its own ribbon menu. HyDraw symbols are located quickly by navigating logically structured menus. Sets of related symbols are shown together and any required symbol can be inserted into the drawing by the drag and drop method. You can insert generic symbols or model code specific component symbols into the library. Edit parametric properties of the inserted symbols, when needed.

HyDraw Library

The HyDraw library accommodates a wide range of simple and complex graphical component symbols, and schematic diagrams covering both Industrial and Mobile Hydraulics. Designed in accordance with ISO1219-1:2012, Fluid Power Systems and Components-Graphic Symbols and Circuit Diagrams-Part 1: Graphic Symbols for Conventional Use and Data Processing Applications. A few percentile deviations from ISO standard necessitated keeping in view the large variants of symbols and customer base. The HyDraw library includes both Slip-in and Screw-in Cartridge valves and associated symbols for manifold design circuits.

Smart Symbols

HyDraw symbols are created using primitive shapes, such as lines, polylines, rectangles, squares, circles, circular arcs, ellipsis. They represent components with specified functions or method of operation in the de-energized (at rest) position, or component specific rule that do not have a clearly defined de-energized position. A pool of ISO specified primitive shapes are included in the library to help you design your own generic symbols. HyDraw symbols also include port identification and port numbering, which is essential for manifold design.

ISO guidelines

VEST has adhered to ISO guidelines of Module System (1Module = 2 Millimeter), where the symbol fits into a grid and presents a symmetry. The use of layer properties for assigning ISO defined color to Supply line, Return line, Pilot line, Drain line, Envelope line, and Flow direction exhibits appealing color graphics, which help in instant understanding of the operational aspect of the component. Layer properties are also utilized for naming ports, positions and solenoids. (both US and European pattern)

Search

The new and powerful HyDraw V700 Search command searches general or OEM specific symbols and circuits from www.FluidPowerTools.com, saving time and effort.

Teamwork

HyDraw helps standardization and teamwork. Multiple users within a local area network can share a common HyDraw library. This enhances productivity of the design and engineering team.

Customization

Customize HyDraw to your specific need using the library and data management console. Save custom components data with symbols tagged to a specific model code and relevant OEM catalog data.

More...

Dynamic Directional Control (DC) Valve design and OEM-specific circuit design with Parts List from component properties held in the library make the software very productive.

Net List creation, Manifold Cost Estimation and interface to FluidPowerTools.com and QuickManifolds.com enable significant cost and time savings.

Work Smart! Use HyDraw[®] today.

2. Support

1 User Manuals

The HyDraw® V700 User Manual provides comprehensive information on the features, commands, usage, processes, and design methodology of HyDraw.

The user manual can be used as a comprehensive reference to the command set and usage of HyDraw.

The Contents and Index listing guides you to relevant material for study and reference.

- ** Click the Help command on the HyDraw V700 ribbon menu to view the user manual in the Adobe Acrobat .pdf format.


2 Support

If you have a question about HyDraw V700 email us at support@VESTusa.com.

Please include the following:

- Version Number of the software you are using.
To see the version of HyDraw on your machine, select **About HyDraw** from the HyDraw ribbon menu in Microsoft Visio.
- Configuration of your machine.
- Exact messages, if any, on the screen.
Send a screen capture, if possible.
- Description of the problem and what you were doing when the problem occurred.
- Description of how you tried to solve the problem.

- *** Click the About HyDraw command on the HyDraw V700 ribbon menu to view the About HyDraw message box indicating the software version number, serial number and the copyright notice.



About HyDraw message box

3. HyDraw Startup

Note: For HyDraw V700 installation refer
Ch. 66

Open HyDraw® V700




Double click the HyDraw V700 desktop
shortcut icon.

Alternatively,

- Click **Start**
- > All Programs
- > VEST
- > **HyDraw V700**


*The program opens Visio and the
HyDraw V700 ribbon menu within the
Visio environment.*



HyDraw V700 opens within Microsoft Visio

4. HyDraw V700 Ribbon Menu

HyDraw® has a new ribbon menu for ready access to the frequently used commands.



HyDraw V700 ribbon menu and submenus

5. HyDraw Library Explorer

The HyDraw® Library Explorer provides access to symbols, external ports, and components. Locate them using either the tree view structure or the search option.

The screenshot displays the HyDraw V700 software interface. The main window shows a hydraulic schematic with various components and connections. The HyDraw Library Explorer is open on the left, showing a tree view of the Component Library. The HyDraw Property Manager is open on the right, showing the properties of the selected item.

HyDraw Library Explorer Component Library:

- Check and Shuttle Valve
- Pump
- Directional Control Valve
- Flow Control and Shut Off Valve
- Pressure Control Valve
- Stackable Valve
- Stackable Valve - Flipped
- Flange Valve
- Proportional Valve
- Servo Valve
- Slip-In Cartridge Valve
- Screw-In Cartridge Valve
- Filter and Strainer
- Hydraulic Motor and Rotary Actuator
- Cylinder
- Manifold and Subplate
- Manifold and Subplate - Flipped
- Gauge, Switch and Measuring Device
- Accumulator
- Heat Exchanger
- Electric Motor
- Hoses and Connectors
- Reservoir and Power Unit components
- Miscellaneous
- Mobile Valves

HyDraw Property Manager Selected Item System:

Item ID	Qty	Model Code	Description
024	1	RES-000000000000	Control Hydraulic
025	1	RES-000000000000	Control Hydraulic
026	1	RES-000000000000	Control Hydraulic
027	1	RES-000000000000	Control Hydraulic
028	1	RES-000000000000	Control Hydraulic
029	1	RES-000000000000	Control Hydraulic

External Ports:

Port	Size
A	{ 1-1/2 BSP }
A2	{ 1/2 BSP }
B	{ 1-1/4 BSP }
B2	{ 1/2 BSP }
DRR1	{ 1/4 BSP }
DR	{ 1/4 BSP }
G	{ 1/4 BSP }
LVL	{ 1-1/4 BSP }
P	{ 1-1/4 BSP }
PR1	{ 1-1/4 BSP }
T	{ 1-1/2 BSP }
TR1	{ 1-1/2 BSP }

Symbols and external ports inserted from HyDraw Library Explorer to design schematic

1 Open HyDraw Library Explorer

- Click **From Library Explorer** from the Insert Symbol option on the HyDraw® V700 ribbon menu within Visio.

Alternatively,

Click  the HyDraw ribbon menu.

The HyDraw Library Explorer dockable window displays and docks on the left of the Visio screen.


2 Move HyDraw Library Explorer

- Select the **HyDraw Library Explorer** using the caption bar and drag or dock it to the desired location.


HyDraw stores the information about the docking location of the Library Explorer.

3 Show/Hide HyDraw Library Explorer

- Use the automatic **Show/Hide** feature of the Library Explorer to maximize the drawing space.
- Click  icon on the caption bar to activate the Show/Hide feature.



HyDraw Library Explorer




Show/Hide HyDraw Library Explorer

4 Load HyDraw Library Explorer on Startup

1. Select  Options from the HyDraw® V700 ribbon menu.
2. Click the **Misc.** tab.
3. Select **Library explorer** from the Load on startup group box.

When subsequently opened, the Library explorer docks to its previous location.



HyDraw Options

6. HyDraw Property Manager

The HyDraw® Property Manager displays assigned properties of the selected items, such as symbols, port connections, connection lines, and systems.

Search the component or model code with given inputs.

Configure your own design requirements and save the data in the library.

The screenshot displays the HyDraw V700 software interface. The main window shows a hydraulic schematic titled "HyDraw Sample Schematic.vsd". On the left, the "HyDraw Library Explorer" window is open, showing a "Component Library" with various hydraulic symbols. On the right, the "HyDraw Property Manager" window is open, displaying the properties for the selected item, "System".

The "HyDraw Property Manager" window shows the following information:

- Selected Item:** System
- Design requirements:** Flow, Pressure
- Model data:**
 - Model Code: 5-4WE10E3X/CG24N9
 - Model Family: 5-4WE10
 - Description: Direction Control Valve
 - Manufacturer: Bosch Rexroth
 - Part Number: R90000000
 - List Price: [blank]
 - Rated Flow(lpm): [blank]
 - Rated Pressure(psi): [blank]
 - Cost: [blank]
 - Assembly Cost: [blank]
 - Pressure Loss @ Rate: [blank]
 - Cavity/Footprint/Interfa D05: [blank]
 - Multifunction Flow(lpm): [blank]
 - Voltage: 24
 - Frequency: DC
 - Bolt Shoulder Height(m): [blank]
 - Installation Torque (All): [blank]
 - Installation Torque (Stk): [blank]
 - Catalog Number: [blank]

Display assigned properties of the selected symbol using the HyDraw Property Manager

1 Open HyDraw Property Manager




Click **Edit** on the HyDraw® V700 ribbon menu

The HyDraw Property Manager dockable window displays and docks on the right side of the Visio screen.

The HyDraw Property Manager displays two tabs


Selected Item and System



Selected Item tab page

Selected Item tab

The Selected Item tab page displays the properties of the selected component and remains collapsed, if the item is not selected in the drawing.



System tab page

System tab

The System tab page displays properties of the complete circuit and the page automatically expands whenever the schematic is opened in the Visio drawing.

When the item is selected or the schematic is open, the respective menu bar expands and the assigned values display.

Click  to expand, if it is not expanded.

2 Dock HyDraw Property Manager


To move the Property Manager window, select it using the caption bar, then drag and dock it to the desired location.

HyDraw stores the information about the docking location of the Property Manager.

3 Load HyDraw Property Manager on Startup

1. Select **Options...** in the HyDraw® V700 ribbon menu.
2. Click the **Misc.** tab.
3. Select the **Property manager** checkbox from the Load on startup section.

Subsequently, the Property Manager opens and docks at its previous location.



HyDraw Options: Misc

7. HyDraw Options

The HyDraw Options command on the HyDraw® V700 ribbon menu enables you to customize HyDraw settings, such as Application, Units, Balloon, Connection, External Port, Parts List, Ports List, Data Path, Misc. Internet settings and QuickManifolds®.


1 Application

Select one of the three applications from Hydraulic, Pneumatic, and Electrical.

1. Click the **Application** tab.
The Application tab page displays.
2. Select the required application: Hydraulic, Pneumatic, or Electrical.
Select any one of the three applications.

The application is selected in the Search From Library tab page in the HyDraw Library Explorer dockable window.

3. Click **OK**.



Application tab page


2 Units

Select units for the selected application.

1. Click the **Units** tab.
The Units tab page displays.
2. Select the required drawing units from Imperial and Metric.


CAUTION!

Units should not be changed after symbol insertion.



Units tab page

3. Click the **Advanced Options**.
The Modify units grid displays.
4. Configure each unit category by selecting the **Primary Unit**.




Units Tab – Advanced Options

5. Select the **Display alternate unit** check box to display the alternate unit along with the primary unit, if required.

The Alternate Unit column displays.


6. Configure the alternate units.
7. Click **Reset** to restore the default units.
8. Click **OK** to apply and exit.



Units Tab – Advanced Options Display Alternate Unit

Note

To display the alternate unit in the old drawing, run **Update Property List** command from the ribbon menu.



Dual Units displayed in the drawing

3 Balloon


Enclose or balloon the envelope ID, external port ID, symbol ID, and accessories ID.

1. Click the **Balloon** tab.
The Balloon tab page displays
2. Select the appropriate numbering scheme to assign ID to schematic, symbol, port, and accessories.
This helps in the identification of the component.

- 1, 2, 3, 4... Items numbered serially
- 1A, 1B, 2A, 2B... Identical items grouped using alphabets
- 1.1, 1.2, 2.1, 2.2... Identical items grouped using dot (.) separator
- 1-1, 1-2, 2-1, 2-2... Identical items grouped using dash (-) separator

ISO 1219 scheme is assigned to symbols

3. Select the **Display in drawing** checkbox, if you want the accessory item ID to be displayed in the drawing.
4. Select the **As sub item of component** checkbox, if the accessory is to be numbered as the sub-item of the component.
5. **Numeric ID** defines the numerical accessory item ID and **Alphabetic ID** defines the alphabetical accessory Item ID.
6. Select the **List component as first sub-item** checkbox, if the component requires the first sub-item to be numbered.
7. Select the required balloon in the Type section.
Select **None**, if you do not want a balloon around an ID.
8. Select the **No balloons on external ports** checkbox, if you do not want any balloon on the external port ID.
9. Click **OK**.




Balloon tab page

- Case1: If numbering scheme 1, 2, 3, 4... is selected, there will be no grouping of identical items.
- Case2: If numbering scheme 1A, 1B, 2A, 2B... is selected, identical sub-items will be grouped and numbered by using Component ID and a Numeric ID separated by chosen Item ID separator, e.g., 2-1A or 2.1A etc.
- Case3: If numbering scheme 1.1, 1.2, 2.1, 2.2... is selected, identical sub-items will be grouped and numbered by using Component ID and a Numeric or Alphabetic ID, whichever chosen, separated by chosen Item ID separator, e.g., 2-1.1 for numeric ID or 2- A.1 for alphabetic ID option etc.
- Case4: If numbering scheme 1-1, 1-2, 2-1, 2-2... is selected, identical sub-items will be grouped and numbered by using Component ID and a Numeric or Alphabetic ID, whichever chosen, separated by chosen Item ID separator, e.g., .2.1-1 for numeric ID or 2.A-1for alphabetic ID option etc.

4 Connection

Customize line properties, line jumpers, line connections, and the recommended velocity in a circuit.

1. Click the **Connection** tab.
The Connection tab page displays.
2. In the Line properties group box, choose the default pressure, tank, pilot, drain, or suction line.
You can also choose other lines with customized name typed in the text box.
3. Click the color box to change the color.
4. Click the combo box to select the line pattern from continuous, phantom, and hidden.
5. In the Line jumper section, select the size of the jumper from large, medium, and small.
*In the Line connection section, select the size of the connection dot from large, medium, and small.
Connection dot is automatically inserted when one line terminates on another.*
6. Set the recommended velocity for Pressure and Return Line.
7. Click **OK** to apply and exit.




Connection tab page

5 External Port

Customize the external port in a circuit.

1. Click the **External Port** tab.
The External Port tab page displays.
2. Click an appropriate button to configure the external port to a circle, oval, line, rectangle, or square shape.
The respective shapes display in the port preview section of the HyDraw Library Explorer window and can be inserted on the envelope line of the circuit.
3. Select the **Middle align** checkbox to align the port co-axially with the envelope line.
This option is applicable only for rectangle and square ports.
4. To displays the Port configuration dialog box during automatic insertion of ports, select the **Show configuration dialog** option.
While automatically inserting Gauge Port the connections are established, per the distance from the main port(X) and the connection distance(Y) value settings.
5. Click **OK** to apply and exit.



External Port tab page


6 Parts List

Customize the Parts List format.


1. Click the **Parts List** tab.
The Parts List tab page displays.
2. To rename a selected format, type the new name in the text box and then click .
3. To add a new format, type the new name in the text box and then click .
4. To delete a selected format, click .
5. Click **Select Columns**.
The Select Parts List Columns dialog box displays.
6. Select the appropriate box and click **OK**.
The selected properties are displayed in the Parts List tab page-Configure columns.
7. Set the Start Column and the Start Row of the Parts List to be inserted into the Excel template.
8. Click **OK**.
The selected properties display in the tabular form, when creating Parts list in the Visio drawing.

Note

To learn more about Parts List, refer Chapter 24.



Parts List tab page



Select Parts List Columns


7 Ports List

Customize the Ports List format.


1. Click the **Ports List** tab.
The Ports List tab page displays.
2. To rename a selected format,
type the new name in the text box and then click .
3. To add a new format,
type the new name in the text box and then click .
4. Click **Select Columns**
The Select Ports List columns checklist box displays.
5. Select the appropriate box and click **OK**.
The selected properties are displayed in the Ports List tab page-Configure columns.
6. Click **OK**.
The selected properties display in the tabular form, when creating Ports list in the Visio drawing.

Note

To learn more about Ports List, refer Chapter 25



Ports List tab page



Select Ports List columns

8 Library Path

Multiple users get easy and hassle free access to the library and the components data from a common source over a network.

1. Click the **Library Path** tab.
The Library Path tab page displays.
2. Select the **Local Library** option.
3. Select the **Enable modification** check box to modify the library.
4. Click **Browse...** and navigate to the folder where the HyDraw® Library data is stored.
The Symbols and Sub-subsystems path are automatically set if the Data, Symbols and Sub-systems folders are located at the same path.
5. Repeat above steps for each of the specified HyDraw library paths, if required.
6. Select the **Corporate Library** option to configure the second library path of your common Network library and repeat steps 3 to 6.
7. Click **OK**.

All the HyDraw library paths are configured.

Data

The folder path that contains component data, library listing data, and manifold manufacturing estimation data are specified.

Symbol Library

The folder path that contains all libraries are specified.

Sub-systems

The folder path that contains user-created circuit drawings and its menu data are specified.

The screenshot shows the 'HyDraw Options' dialog box with the 'Library Path' tab selected. The dialog has a title bar with a close button. Below the title bar is a tabbed interface with the following tabs: Application, Units, Balloon, Connection, External Port, Parts List, and Ports List. The 'Library Path' tab is active and contains the following options and fields:

- Local Library** (selected):
 - Enable modification
 - Data: D:\VEST\HyDraw Library 2013\Data (with Browse... button)
 - Symbols: D:\VEST\HyDraw Library 2013\Symbol Library (with Browse... button)
 - Sub-systems: D:\VEST\HyDraw Library 2013\SubSystems (with Browse... button)
- Corporate Library** (not selected):
 - Enable modification
 - Data: \\WEST\HyDraw Library 2013\Data (with Browse... button)
 - Symbols: \\WEST\HyDraw Library 2013\Symbol Library (with Browse... button)
 - Sub-systems: \\WEST\HyDraw Library 2013\SubSystems (with Browse... button)

At the bottom right of the dialog are 'OK' and 'Cancel' buttons.


LibraryPath tab page

Note

All data paths shown are default.
You can configure to common network data paths.

9 Misc.


1. Configure the text size, envelope line, symbol color, and solenoid naming in the US and Europe pattern.
2. Load the HyDraw® Library Explorer and the HyDraw Property Manager into your Visio drawing during Startup.
3. Click **Misc.** to display the tab page.



Misc. tab page

9.1 Text Size


1. In the Text size group box, select the appropriate text size from the respective list box for item ID, display properties, and list items.
2. Click **OK** to affect the changes to the properties in the library.



Text size section

9.2 Envelope Line


1. In the Envelope line group box, select the appropriate line pattern from continuous, phantom, and hidden list box options.
2. Click the **Color** button to open the color box and select the required color.
3. Click **OK** to effect the changes in the library.



Envelope Line section

9.3 Load on startup

1. The Library Explorer and Property Manager can be loaded to HyDraw® on startup.
2. In the Load on startup group box, select the application you want to use for loading on startup.
The selected application loads and docks to the HyDraw drawing.
3. Click **OK** to affect the changes.




Load on startup section

9.4 Symbol Color

All symbols in the HyDraw® library are assigned with the ISO defined colors.

You can also have these symbols in black color.

1. Select the checkbox in the Symbol color section, if you want to change the color of symbols to black.
2. Click **OK** to affect the changes in the library.




Symbol color section


9.5 Solenoid Naming

Solenoids in the Directional Control Valve symbols are named both in the US and Europe pattern using the Visio layer properties. You can view only one pattern at a time.


1. Select the appropriate pattern.
The selected pattern will affect the change of solenoid naming of symbols in the HyDraw® drawing.
2. Click **OK** to effect the changes.



Solenoid naming section




Solenoid naming – US pattern



Solenoid naming – Europe pattern

10 Internet Settings


Configure the Internet connection for FluidPowerTools and QuickManifolds®.

Click  on the QuickManifolds section of the HyDraw® V700 ribbon menu.

The Internet Settings of the HyDraw Options dialog box displays.

Note

Refer chapter 2.6 for detailed configuration.



The image shows the 'HyDraw Options' dialog box with the 'Internet Settings' tab selected. The dialog has a title bar with a close button. Below the title bar is a tabbed interface with tabs for 'Application', 'Units', 'Balloon', 'Connection', 'External Port', 'Parts List', and 'Ports List'. The 'Internet Settings' tab is active and contains the following configuration options:

- Automatically detect settings
- Use proxy server
 - Address:
 - Port:
- Enable authentication
 - User Name:
 - Password:

Note: You must restart Visio for settings to take effect.


At the bottom right of the dialog are 'OK' and 'Cancel' buttons.

HyDraw Options – Internet Settings

11 QuickManifolds

Preserve QuickManifolds.com Logon information and select the Design data library.

1. Click the **QuickManifolds®** tab.
The QuickManifolds tab page displays.
2. Enter the Logon information, i.e. User Name and Password.
The user name and password are preserved and used to logon to QuickManifolds.com
3. Select **QuickManifolds Library** or set the **My MDTools Library** path to use the corresponding library for the QuickManifolds design.



The screenshot shows the 'HyDraw Options' dialog box with the 'QuickManifolds' tab selected. The dialog has a title bar with a close button. Below the title bar is a tabbed interface with the following tabs: Application, Units, Balloon, Connection, External Port, Parts List, Ports List, Library Path, Misc., Internet Settings, QuickManifolds (selected), and ERP Settings. The 'QuickManifolds' tab contains two sections: 'Logon information' and 'Design data'. The 'Logon information' section has a 'User Name' field containing 'jpanda@vestusa.com' and a 'Password' field with masked characters. The 'Design data' section has two radio buttons: 'QuickManifolds library' (selected) and 'My MDTools library'. Below the radio buttons is a 'Path' field and a 'Browse...' button. At the bottom right of the dialog are 'OK' and 'Cancel' buttons.

HyDraw Options – QuickManifolds

12 ERP Settings


Preserve the ERP settings.

1. Click the **ERP Settings** tab.
The ERP Settings tab page displays.
2. Select **My local ERP data** and select the Excel file path by clicking **Browse...**
Or
Select **Online ERP data** and enter the Service URL.
3. Select the **Search using** options, which is either the model code or the part number.
4. Enter the **ERP column name**.
5. Click **OK** to save the ERP settings and quit HyDraw Options.

Note

Configure and place the ERPServiceConfiguration.xml at the same location, where the ERP data file in Excel format is saved.

For details, refer Chapter 73. Configure the ERPServiceConfiguration.xml.



HyDraw Options – ERP Settings

Inserting Symbols

The screenshot displays the HyDraw V700 software interface with a hydraulic schematic. A central menu lists the following options:

- 8 Inserting Symbol
- 9 Inserting External Port
- 10 Inserting Gauge Port
- 11 Searching Components
- 12 Searching Sub-systems
- 13 Inserting from Parts List
- 14 Inserting from DC Valve Configurator
- 15 Inserting Envelope

Key annotations on the schematic include:


- Pilot Line:** A pink box pointing to a vertical line on the left.
- Pressure Line:** A pink box pointing to a horizontal line connecting two valve assemblies.
- Drain Line:** A pink box pointing to a vertical line from a valve to a drain symbol (OV2).
- Tank Line:** A pink box pointing to a vertical line from a valve to a tank symbol (OV7).
- Connection Dot Inserted Automatically:** A pink box pointing to a blue dot on a horizontal line.
- Jumper Inserted Automatically:** A pink box pointing to a red curved line connecting two lines.

The schematic shows two valve assemblies, S1 and S2, with various ports (A, B, P, T, Y) and cylinders (S1 Cylinder Up, S1 Cylinder Ext., S2 Cylinder Ret.). Other components include RC, OV3, OV5, and OV6.

8. Inserting Symbol

Insert symbols, external ports, and component models into the drawing.

The Component library is a logically structured symbol library of hydraulic, pneumatic, and electrical systems.




Logically structured Component Library

1 Insert a symbol into the drawing

1. Select the appropriate library and navigate to the required symbol.
2. Drag the symbol from the HyDraw® Library Explorer window into the drawing.

Note:


The Mobile Valve symbols are smart symbols and they can be configured from the context menu by right clicking over the symbol.



Drag and drop symbol from Component Library into the Visio drawing

2 Replace Symbol

1. Select the **Replace symbol** checkbox in the HyDraw Library Explorer window to replace the symbol in the drawing, if required.
3. Drag and drop the new symbol over the old symbol in the drawing.



Replace Symbol from Component Library into the Visio drawing


9. Inserting External Port

Insert ports on the envelope line in a circuit drawing.
Configure and edit the ports to suit the circuit requirements.

1. Click  tab on the HyDraw® Library Explorer window.
The External Port Library tab page displays.
2. Click  on the Configure External Port caption bar to expand, if the section is not open.
3. Type the **Item ID** in the text box,
for example, P, T, 1.
The default Item ID is '?'.
The default Item ID is '?'.
4. Select **Pressure line port** or **Return line port**.
5. Enter parameters for **Pressure** and **Flow**.
6. Select **Port Type** from SAE O-ring, SAE Flange, BSP, NPT, and Metric.
On selection, different port sizes of the respective port type are displayed automatically.
Choose the required one.
7. Select and drag the plugged or unplugged port from the preview section into the drawing.
If the port symbol is placed over the envelope line, it attaches itself to the envelope line.
When moved, it moves along the envelope line.

When a connecting line connects to the envelope line, an external port is inserted automatically at the point on the envelope.


The port displays a red square with white background.
When a proper connection is made, the red square disappears.




External Port Library tab page

1 Replace External Port

1. Replace the port in the drawing with another port from the library by selecting the symbol.
2. Select the **Replace symbol** checkbox in the HyDraw® Library Explorer window, if required.
3. Drag and drop the new symbol over the old symbol in the drawing.



External Port inserted into the drawing



Replace symbol, Unplugged with Plugged External Port

2 Fetch Port from Library


1. Select the external port.

In the HyDraw Property Manager, Selected Item, specify the Design requirements, Pressure, and Flow.


2. Click  in the Design requirements section.
4. *The Edit Port Operating Parameters dialog box displays.*
3. The Flow and Pressure are automatically picked up from the Design requirements. If any changes are required, modify and click **OK**.
4. Select the **Fetch from Library** icon.
5. *The Fetch Port from Library dialog box displays.*
5. Select **Pressure line port** or **Return line port**.
6. Select **Port type** on the basis of the design requirements.
The port size is automatically selected.
7. Click **OK** to apply and exit.

Note

The port data can embed **With O-ring** and **With Through Bolt Hole** from HyDraw® to MDTools®.



Edit Port Operating Parameters



Fetch Port from Library


3 Configure External Port

Configure external ports to different shapes.


1. Select  Options from the HyDraw® V700 ribbon menu.
2. Click the **External Port** tab.
The External Port tab page displays.
3. Click the appropriate shape to configure the port shape to a circle, oval, line, rectangle, or square.
The respective shape displays in the Port Preview section of the HyDraw Library Explorer window.

The external port can be placed on the envelope line of the circuit.
4. Select the **Middle align** checkbox to align the port co-axially with the envelope line.
This option is applicable only for rectangular and square ports.
5. Select the **Show configuration dialog** checkbox to display the Configure Port dialog box, when the ports are automatically inserted on the envelope line by drawing a connection line.

Alternatively, the Configure Port dialog box appears on clicking the Fetch from Library Icon from the HyDraw Property Manager.
6. Click **OK** to apply and exit.



External Port tab




Configure Port dialog box

10. Inserting Gauge Port

Automatically add a gauge port in parallel to an existing external port.

1. Set the **Gauge port insertion distance** default values in the External Port tab of the HyDraw[®] Options dialog box.
2. Select the external port in the circuit drawing, where you want to add the gauge port in parallel.




External Port tab, set the gauge port distances

Configure the External Port

1. Select the **Insert a gauge port** check box in the External Port Library tab.
2. Drag and drop the gauge port symbol on the side of the selected external port, where you want it to be inserted.

The gauge port is inserted and connected in parallel to the selected external port.



Gauge port G1 is inserted in parallel to the existing selected external port

11. Searching Components

The Search From Library feature is used to search a component or sub-system from the library. Search the Model Family or Model Code of a component type or category of a particular manufacturer or different manufacturers.

1 Search Components


1. Click  tab on the HyDraw® Library Explorer window. The Search From Library tab page displays.
2. Select **Components**.
3. Select the appropriate application.
4. Select appropriate search database, My local database or FluidPowerTools.com database.

If the My local database option is selected, the program searches components in the user's local database.

If the FluidPowerTools.com database option is selected,

The split button on the right is enabled, use the data access settings.


In Data Access Settings, select the manufacturer database to search components.



Data Access Settings

The Data Access Settings drop down provides other controls, which includes:

- Data Access Settings
- Data Library & Help
- Usage terms and conditions
- My Subscription information
- Contacts...



Default Search tab page

5. Select the manufacturer from drop-down list, if *My local database* is selected.



Manufacturer options


6. Manufacturer options
Enter the Model Code to search the particular component
For precise search, define custom search parameters in the Define more criteria section.

Click  to view the Select Property box, which displays all possible properties

Select the property you want to assign.


Enter the property value, for example 10,
or range, for example 10-20.
Property range must be separated by a hyphen (-).n

7. Select the appropriate component type.




Component type options

8. Enter Model Code.




Enter Model Code

9. Define more criteria.



Define More Criteria options

10. Select Property



Select Property

11. Click the **Search for Model Code** button.


All model codes with the assigned custom properties are displayed in the Search results pane.



Searching model code with precise criteria

12. Select the appropriate model code in the preview pane.


The Search results are displayed in the pane.




Preview symbols

13. **Right click** and select **View Model Properties** from the context menu to display the component data window.

The **Component Model Properties** window displays details about the component.




Model code context menu



Component data


14. Click search for **Model Family**.

All model families with assigned custom properties are displayed in the Search results pane.




Model Family search results

15. Right click and select **Search for Complete Model Code** from the context menu to display all model codes in the model family.




Model Family context menu

16. Click **Modify Search** to return to the main search window and search with different inputs, if required.



Modify Search


17. **Select** the symbol in the preview pane; drag and drop it into the drawing.
18. **Replace** the symbol in the drawing with another one from the library by selecting the **Replace symbol** checkbox in the HyDraw® Library Explorer window, if required.
19. **Drag** and drop the new symbol over the old symbol in the drawing.



Symbol dragged and dropped into the drawing


12. Searching Sub-systems

1. Click  tab on the HyDraw® Library Explorer window. *The Search From Library tab page displays.*
2. Select **Sub-systems**.
3. Select the appropriate application.




Sub-systems tab page

4. Select the appropriate category.



Category options


5. Select the appropriate manufacturer.




Manufacturer options

6. Enter the Model Code to search the particular component

- For precise search, define custom search parameters in the Define more criteria section.
- Click  to view the Select Property box, which displays all possible properties.
- Select the property you want to assign.
- Click OK.




Searching model code with precise criteria




Select Property

7. Click the **Search** button.
All sub-systems with assigned custom properties display in the Search results pane.

8. Click on the search results to display the selected sub-system in the preview pane.
The Component Model Properties window displays details about the sub-system.




Search Model Code




Component Model Properties

- Right click and select **View Model Properties** from the context menu to display the component data window.



View data

- Select the sub system in the preview pane; drag and drop it into the drawing.



Sub-system dragged and dropped into the drawing


13. Inserting from Parts List

Insert symbols from Parts List in the Excel sheet. Each part in the Parts List is identified by its unique model code. Therefore, the parts list must contain a model code for each part in the list.

Insert Symbols from Parts List


1. Select **From Parts List** from the Insert Symbol option on the HyDraw® V700 ribbon menu.

The *Insert Symbol from Parts List* dialog box displays.



Insert Symbols From Parts List dialog box


2. HyDraw sets **Part list starting rows at** from the HyDraw Options – Part List or you can enter the value.
3. Enter **Model Code column number** in the textbox, if you know.



Select Parts List Excel File dialog box

4. Click **Browse...**
The *Select Parts List Excel file* dialog box displays.
5. Select the required file.

6. Click **Open**.
7. The complete Parts List displays in the Excel sheet.
8. Select the part or component symbol you require.
9. Click **Insert** to insert it into the drawing.
A message box displays and notifies to select a point on the drawing, where you want to insert the symbol.
10. Click **Cancel**, if you want to abort the command.
11. Select the point on the drawing, where you want to insert the symbol.
The symbol displays on the drawing.




Insert Symbol from Parts List dialog box

12. Click **Insert All** to insert all symbols from the list into the drawing.

Note

- Envelopes and accessories are not inserted.
- Components without Model Code are not inserted.

The components (rows), which are not inserted, are highlighted in red.




Symbol inserted into the drawing

14. Inserting from DC Valve Configurator


Configure dynamically both proportional and non-proportional stackable and non-stackable Direction Control (DC) valves with customized flow paths. Insert the configured valve into the drawing.

1. Select **From Configure DC Valve** from the Insert Symbol option on the HyDraw® V700 ribbon menu.
The DC Valve Symbol Configurator dialog box displays.
2. Select the **Proportional DC valve** checkbox, if you want to configure the proportional DC valve from the Valve type group box.




DC Valve Symbol Configurator window

3. Select the appropriate **operator**.




Operator options

4. Select the appropriate **function**.




Function options

5. Select the appropriate **size**.
6. Select **Stackable symbol**, if you want to configure a stackable valve.
7. Click **Change pattern**, if you want to make any changes.
The Select Pattern dialog box displays and shows the available patterns.




Size options

- Select the appropriate pattern and click **OK**.
The *Directional Control valve symbol displays in the pane.*




Different Patterns

- Click **Show Preview** to view the selected DC valve in the preview pane.




Dynamically configured DC valve preview window

- Click each “?” box in the Flow Path section to select the appropriate flow path.
The *Select Flow Path window displays.*



Select Flow Path window

- Click **Insert to Drawing** to insert the symbol into the drawing.
The *symbol is inserted into the drawing.*



Dynamically configured DC valve inserted into the drawing

15. Inserting Envelope

Insert an envelope to define a boundary for a manifold or a system.


1. Click  Envelope from the HyDraw® V700 ribbon menu.

The Visio cursor changes into a small square box.

2. Select a point on the drawing, click and drag to create an envelope. The selection point and endpoint mark the diagonal corner points of the envelope.
3. To resize the envelope, select the envelope and drag it by the mid-selection point or the corner selection point.

Note

- By default, the size of the envelope is unlocked.
- It must be unlocked using the (Un)Lock Size command, before resizing it.



Ribbon menu for Envelope, Terminator, Interruption Points, and Connection Points



Envelope defining the boundary of a symbol



Resizing the envelope

Making Connections

HyDraw Sample Schematic.vsdX - Visio Professional

FILE HOME INSERT DESIGN DATA PROCESS REVIEW VIEW DEVELOPER HyDraw V700

16 Inserting Connection
17 Connecting Lines, Ports, and Symbols
18 Fetching Pipe and Tube Data from Library
19 Inserting Terminators
20 Inserting Interruption Point
21 Inserting Connection Point

Pilot Line

50 bar

Pressure Line

Drain Line

Tank Line

Connection Dot Inserted Automatically

Jumper Inserted Automatically

OV2

OV3

OV5

OV6

OV7

S2 Cylinder Down

S1 Cylinder Up

S1 Cylinder Ext.

S2 Cylinder Ret.

Page 1 | All | +

PAGE 1 OF 1 WIDTH: 1.732 IN. HEIGHT: 0.63 IN. ANGLE: 0° ENGLISH (UNITED STATES)

50%

16. Inserting Connection

Interconnect symbols and create a circuit. Jumpers and line connections or connection dots are inserted dynamically, where connecting lines cross each other or where one connection line terminates on the other.

1. Click **Insert Connection** on the HyDraw® V700 ribbon menu.
2. Select the Connection type from Pressure, Tank, Pilot, Drain, Suction, or, Custom from Line1, Line2, Line3, Line4, and Line5.
Connection lines are assigned with default ISO color and line weight.

You can customize the connection lines.

Line Connection and Line Jumper

Line connection or Connection dot is inserted, where one line terminates on the other.


When the connection is not intended, lines are shown crossing each other or jumping over the other.

- Select the appropriate size of the connection dot and jumper from the Options menu.

Connection dot and jumpers are inserted dynamically.

Note

The connection line properties cannot be applied to multiple selections.



Insert Connection submenus

17. Connecting Lines, Ports, and Symbols

1. Select the Connection type from Pressure, Tank, Pilot, Drain, Suction, or Custom from Line1, Line2, Line3, Line4, and Line5 from the HyDraw® V700 ribbon menu.

Connection lines are assigned with default ISO color and line weight. You can customize the connection lines.

2. Select any point on the drawing, where you want to start or end the connection.
3. Specify the start point of the connection and drag to the endpoint, where you want the connection to terminate.
4. To connect two ports of different symbols, click one port of a symbol and drag to the other port.

The connection line snaps to end points and becomes straight dynamically, if drawn with kinks.


5. To connect one port of a symbol with the envelope line, click the port of the symbol and drag on to the envelope line or vice versa.

External port is inserted dynamically on the envelope line, when a line connects the envelope line.

When two lines cross each other, a jumper is inserted over one line dynamically. This indicates the connection is not intended.

When one line terminates on another, a connection dot is inserted dynamically on the connection point.


6. To move the connection line, select and drag the connection line by the mid point to the desired position.
7. To stretch the connection line, select and drag the connection line by the endpoint to the desired position.
8. .To deletes a connection line, select the connection line and press the Delete key.




Insert Connection submenus

Note

- When you connect a connection line to a symbol port, the red square at the port connection point disappears. This indicates that the connection line is connected to the symbol properly.
- To insert Jumpers automatically for non-intersecting connection lines, set this option in the Misc. tab of the HyDraw® Options ribbon menu.
- Connection dots are inserted automatically when one connection line terminates on the other.
- When you delete the connection line, the red square at the port connection point becomes visible again. This indicates that the port connection point is unattached.



Stretch connection by endpoint



Connection lines inserted to create circuit


18. Fetching Pipe and Tube Data from Library

Connection lines can be assigned with the Tube and Pipe data from the Library based on the design requirements.


1. Select the **connection line**.
2. Specify the Design requirements, Pressure and Flow for the selected connection line in the **HyDraw Property Manager**.
3. Click the **Fetch from Library** icon.
6. *The Fetch Pipe/Tube from Library dialog box displays.*
4. Select either the **Pressure Line** or the **Return Line**.
5. Select the **Type**, i.e. Tube/Pipe.
6. Select the **Material**.

The available Tubes and Pipes are displayed based on the design requirements and velocity.

7. Select the pipe or tube.
8. Click **OK** to select and exit.



HyDraw Property Manager – Connection Data



Fetch Pipe/Tube from Library

19. Inserting Terminators


Insert terminators dynamically at the unused component ports and unconnected connection lines.

1. Select the symbols or the circuit lines for the terminator insertion.
2. Click **Terminator**  from the HyDraw® V700 ribbon menu.

Terminators are inserted automatically at all the unused ports of all selected symbols and unused connection lines.

Note

- The terminator indicates the unused component port.
- Terminator is essential in the Net List creation.
A net remains incomplete, if a port is left unconnected.
- The Net List can indicate unconnected circuit lines and ports.



Inserting dynamic terminators

20. Inserting Interruption Point

Insert interruption points to correlate connection lines, parts of which lie on different pages in the Visio drawing file. This is applicable for larger schematics that spread into multiple pages.


The *Interruption Point –Outgoing* notifies the outgoing connection on the connection line on the page.

The *Interruption Point –Incoming* notifies the corresponding connection on the connection line on a different page.

Insert Interruption Point – Outgoing

- Select **Interruption Point – Outgoing**  from the HyDraw® V700 ribbon menu.

An *Interruption Point –Outgoing*  is inserted automatically at the outgoing connection line.




Interruption Point –Outgoing

Insert Interruption Point – Incoming

- Select **Interruption Point – Incoming**  from the HyDraw V700 ribbon menu.

An *Interruption Point –Incoming*  is inserted automatically at the incoming connection line.




Interruption Point – Incoming

21. Inserting Connection Point

Insert connection points on the ports of a symbol.

1. Select the symbol.
2. Click **Connection Point**  on the HyDraw® V700 ribbon menu. *The Insert Connection Point dialog box displays.*




Assigning port name

3. Type the **Port name** and the optional **Other name** in the text box. *The name should be the same as that of the port on which you want to insert the connection point, for example, P. Do not enter any other character other than the port name.*

Note

The connection points inserted using the Visio commands will not function correctly in HyDraw®.

4. Click **Insert**. *The message, Press 'Ctrl' and Click to add connection point, displays in the Insert Connection Point window. Simultaneously, the cursor changes to a small cross in the drawing.*
5. Move the pointer at the point on the symbol, with the Ctrl key pressed, to the place where you want to insert the connection point. Then, click to add the connection point.



Inserting connection point

Specifying Properties

The screenshot displays the VEST HyDraw V700 software interface. The main window shows a hydraulic schematic with various components and piping. A blue callout box highlights a list of property-related actions:

- 22 Selected Item Properties
- 23 System Properties
- 24 Copying Properties
- 25 Refreshing Properties
- 26 Updating Property List
- 27 ERP Interface

The interface includes several panels:

- HyDraw Library Explorer:** Shows a component library with categories like Check and Shuttle Valve, Pump, Directional Control Valve, etc.
- HyDraw Property Manager:** A window on the right showing the selected item's properties, including design requirements, model data (cost, pressure loss, voltage, frequency, etc.), and accessories.
- Properties Panel:** A table at the bottom right of the schematic showing item ID, name, and description for various components like 'ROLL CYL. EXTEND' and 'PITCH CYL. RETRACT'.

At the bottom of the window, there is a navigation bar with 'Page 1 | All' and a status bar showing 'PAGE 1 OF 1 | WIDTH: 2.205 IN. | HEIGHT: 0.63 IN. | ANGLE: 0° | ENGLISH (UNITED STATES)'.

22. Selected Item Properties

Display the assigned properties of the selected symbol in the drawing. Add new accessories to the symbol and save in the library.

Select the symbol on the drawing.

The Selected Item tab page displays the following sections


1 Symbol

The Symbol section displays the ID, balloon style, and various settings of the symbol.

- Customize the balloon style to circle, oval, rectangle, rounded rectangle, or none of these.
- Show or Hide various settings with the symbol on the drawing.

Click  to expand and then select **Hide/Show** to hide or show the respective parameter.

- Select the checkbox on the caption bar to include the Selected Item properties in the respective component Parts List of the circuit.



The screenshot shows the HyDraw Property Manager dialog box with the Selected Item tab selected. The dialog is divided into several sections:


- Symbol**: Includes a checkbox for "Include in Parts List" and fields for Item ID (1-0V1), Assembly ID, Balloon Style (Rounded Rectangle), and a checked "Display Setting" checkbox.
- Design requirements**: Fields for Flow (gpm) set to 20 and Pressure (psi) set to 5000.
- Model Data**: A list of properties including Model Code (CXDAX**), Model Family (CXDA), Part Number, Description (Check Valve), Manufacturer (Sun Hydraulics), Cost, Assembly Cost, List Price, Rated Flow (gpm) (20), Pressure Loss @ R, Rated Pressure (psi) (5000), Type, Cavity/Footprint/Inte (T-13A), Cracking Pressure, Installation Torque (30-35 lb.ft./45-50 Nm), and Catalog Number.
- Accessories**: A section with icons for adding, deleting, and saving accessories.
- Linked data**: A section with a checked "Documents" checkbox and a list containing "Data Sheet" and "ProductRedirect.aspx?ModelCode=CXDA".

Selected Item tab page

2 Design Requirements


The Design Requirements section enables you to search the required components with a specific parameter and value, for your design, from the library.

- Type the value in the text box of the respective parameter.
- Click  on the **Design requirements** caption bar to open the **Edit Design Note** page to make relevant entries for future reference.
- Click  on the **Design requirements** caption bar to open the **Edit Port Operating Parameters** dialog box.
- The flow and pressure are automatically selected from the Design requirements. If any changes are required, then modify and click **OK**.



The screenshot shows the Edit Design Note dialog box, which is a simple text area for entering notes. It has "OK" and "Cancel" buttons at the bottom.

Edit Design Note



The screenshot shows the Edit Port Operating Parameters dialog box. It has a "Port name" list with items 1 and 2. To the right, under "Operating parameters", there are input fields for Flow (20 lpm) and Pressure (5000 bar). It has "OK" and "Cancel" buttons at the bottom.

Edit Port Operating Parameters

3 Model Data

The Model Data section displays the details of the component selected.

Fetch from Library

- Fetch model data for a component using either the
Local database installed on the system
OR
Online database of FluidPowerTools.com
- Enter the required criteria in the Model Data section.
- Click  on the Model Data caption bar to fetch the component from the library.


The Fetch from Library dialog box displays with the input data.

- Select the database to search, i.e.,
My local database or Fluidpower.com

*If the My local database option is selected,
the program searches the component in the local database of the user.*

*If the FluidPowerTools.com database option is selected,
the split button on the right is enabled,
use data access settings.*

- In the Data Access Settings, select **manufacturer database** to search components.



Fetch from Library - Data Access Settings

*The Data Access Settings drop down provides other controls,
which includes:*

Data Access Settings, Data library & Help topic, Usage terms and conditions, My Subscriptions information, and Contacts.

- Click **Models linked to symbol** to display the component models linked to this symbol.
- Click **All models** to display all component models available to the component type of the symbol.
- Click the **Search** button to search for the component.

The search results display in the Search results pane.

- Click **OK**.

Add Accessories

You can add or replace accessories of the model code to the symbol by selecting an appropriate button.

- Select the **Include accessories** check box, and then select **Add**.
The linked accessories of the component model will be added to the selected model.

Replace Accessories

- Select the **Include accessories** check box, and then select **Replace**.
The linked accessories of the component model will be added to the selected model and all accessories linked previously will be delinked.


Saving Model Data into Library

You can save the designed component with customized data in the library.


- Click  on the Model Data caption bar to save custom details in the library.

Note:

To undo the changes, use the **Undo** function in Visio.



Fetch from Library with Search results



Save to Library

4 Accessories

The Accessories section displays the details of accessories assigned with the item.

This section also displays all documents and CAD files linked with the accessory.

Select from Library

You can fetch required accessories to your component from the library.

1. Click  on the Accessories caption bar.

The Select Accessories from Library dialog box displays.

2. Select the required manufacturer and component type.
3. To refine the search, type the Model Code, and then click **Search**.

All available accessories of the selected component type display in the Available accessories pane.


4. Define more criteria,

For precise search, define custom search parameters.

- Click  to view the Select Property box, which displays common properties of the selected Model.
- Select the property you want to assign.
- Click **OK**.

5. Click Search.

All available accessories of the selected component type display in the Available



Select Accessories from Library

Model Code: CG Manufacturer: All Manufacturers

Component type: Bolt Kit

Define more criteria

Nominal Size: ... 1

None ...

None ...

Available accessories

Model Code	Manufacturer	Description
CG24	Baldor	Bold Kit

Add

Selected accessories

Model Code	Manufacturer	Description	Quantity
CG24	Baldor	Bold Kit	1

Remove

OK Cancel

Fetch Accessories from Library

accessories pane.

6. Select the model code you want to add to your circuit.
7. Click **Add**.

The added model codes display in the Selected accessories pane.

8. Select the model code and click **Remove** to remove the selected model code from the selected accessories pane.
9. Click **OK**.

All the selected accessories are added to the component and displayed in the Accessories pane on the Selected Item tab page.

Select Accessories from Library

Model code: Manufacturer: All Manufacturers

Component type: Bolt Kit

Define more criteria

None

None

None

Available accessories

Model Code	Manufacturer	Description
BK-12	Eaton	Bolt Kit

Selected accessories

Model Code	Manufacturer	Description	Quantity
BK-12	Eaton	Bolt Kit	1

Selected accessories

Select Property


Description
None

Select Property dialog

Add New Accessories

You can add new accessories to the selected item and save in the library.

- Click  on the Accessories caption bar.
The Add New Accessory dialog box displays.
- Select the appropriate component type you want to add.
- Click **OK**.
The accessories are assigned to the component and displayed in the Accessories pane.
- Click  to expand the newly added accessories menu.
- Fill in the required data in the appropriate text box.




Add New Accessory window


Save Accessories

You can save the newly added accessories to the component.

- Click  on the Accessories caption bar.
The Save to Library dialog box displays.
- Click **OK**
The new accessories are saved.



Accessories section




Save to Library

Delete Accessories

- Select the accessory you want to remove.
- Click  on the Accessories caption bar to delete the accessory.

The accessory is deleted from the component.




Accessories deleted from library

5 Document

The documents linked with the selected component model are displayed. You can delete and link documents from the library.

Click  on the **Documents** caption bar to delete the linked document.

Click  **Select from library** to link new documents to the selected component model.




Document

6 CAD Files

The CAD files linked with the selected component model are displayed. You can delete and link CAD files from the library.

Click  on the **CAD Files** caption bar to delete the linked CAD files.

Click  **Select from library** to link new CAD files to the selected component model.



CAD Files

23. System Properties

When you open a schematic in the Visio drawing, the System tab page displays the assigned properties of the selected system in the drawing. Add new accessories to the system and save in the library.

1. Components

The Components section displays the model codes of all the components in the circuit.

- Select the Item ID to highlight the corresponding component in the drawing.

2. External Ports

The External Ports section displays the ID and the size of all external ports in the circuit.

- Select the Item ID to highlight the corresponding external port in the drawing.


3. Envelopes

The Envelopes section displays the ID of the envelopes.

- Select the Item ID to highlight the corresponding envelope in the drawing.

4. Accessories

The Accessories section displays the details of accessories assigned with the circuit.



Schematic

Selected Item	System
OV5	{ FDCB-LAN }
OV6	{ FDCB-LAN }
OV7	{ 5-4WE10E3X/CG24N9 }
OZ10	{ BR210 }
OZ3	{ P30-100 }
OZ4	{ G300 }
OZ5	{ D225M/SAEB }
OZ6	{ 400-M60-BB }
OZ7	{ 721-20 }
OZ8	{ 50AS105QEBPGG20 }
OZ9	{ LS167 }

External Ports	
A	{ 1-1/2 BSP }
A2	{ 1/2 BSP }
B	{ 1-1/4 BSP }
B2	{ 1/2 BSP }
BR	{ 1/2 BSP }
DRR1	{ 1/4 BSP }
DR	{ 1/4 BSP }
G	{ 1/4 BSP }
LVL	{ 1-1/4 BSP }
P	{ 1-1/4 BSP }
PR1	{ 1-1/4 BSP }
T	{ 1-1/2 BSP }
TR1	{ 1-1/2 BSP }

Envelopes	
OZ1	{ Reservoir }
OZ2	{ Envelope }

System tab page


24. Copying Properties

Copy component data, design requirements, and accessories, if any, of one component symbol with another component symbol of the same category.

1. Select the source component symbol in the HyDraw® drawing.
The data of the component can be viewed from the Selected Items properties tab page in the HyDraw Property Manager.
2. Click **Copy Properties**  **Copy** on the HyDraw V700 ribbon menu.
The Copy Properties dialog box displays.

Note

3. The command becomes available only when the source symbol is selected.
4. Select the required properties you want to copy from the Model data checklist box.
5. Select the required design requirements, if you want to copy from the **Design requirements** checklist box.
6. Select the **Include accessories** checkbox, if you want to copy the accessories to the destination symbol.
7. Select **linked documents** and **linked CAD files** checkboxes, if you want to copy the linked documents and CAD files to the destination symbol(s).
8. Select the destination symbol(s), for the properties of the source symbol to be copied to.
The properties are copied to the destination symbol(s).




Copy Properties



25. Refreshing Properties

Update property values of symbols or the system from HyDraw® Library.

1. Click **Refresh properties**  on the HyDraw V700 ribbon menu.
The Refresh Properties dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the items to be included,
 - Select the **Components** checkbox to include all components in the Refresh properties.
 - Select the **Component accessories** checkbox to include all component accessories in the Refresh properties.
 - Select the **System accessories** checkbox to include all system accessories in the Refresh properties.
4. Click **Next**.
The Refresh Properties value dialog box displays.
5. Select individual properties to Refresh or **Select All**.
6. Click **OK**.
The Update message box displays.
7. Click **OK** to apply and exit.



Refresh properties



Successful Update message

26. Updating Property List


Update the properties of symbols or system from the HyDraw® Library. Display properties with the alternate units.

1. Click **Update Property List**  Update Property List on the HyDraw V700 ribbon menu.


The Update Property List dialog box displays.

2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the **Components**, **External Ports**, **Connection Lines**, **Component accessories** and **System accessories** checkbox to include in the Update Properties List.
4. Click **Next**.
5. Select the items to be included,
 - Add new model and design properties
 - Add new display formats
 - Update property definitions
 - Delete unused properties
6. Click **Back** to change the selection.
7. Click **Update**.


The Update Property List message box displays the status.
8. Click **OK** to apply and exit.



Update Properties List



Selected properties to update




Update Status message


27. ERP Interface

Fetch the data from the ERP data file in the Excel format.

1. Click  on the HyDraw V700 ribbon.
The Select item dialog box displays.
2. Select any one of the three options:
Click the **Active** page button to select the drawing in the Active page.
Click the **All pages** button to select the whole document in the file.
Click the **Selected symbols** button to select the specified component symbols.
3. Select the **Components**, **Component accessories** and **System accessories**, as required.




ERP Interface-Select item dialog



Select Model dialog

4. Click **OK**.
The Fetch Data From ERP dialog displays.
The columns get populated with the matching Model codes values
Partially matching Model Codes are displayed with the Select link.
 - a. Click the Select link.
7. *The Select Model dialog box displays.*
 - a. Select the Model Code, as required.
 - b. Click **OK**.
The highlighted cells indicate the matching values with the selected components & accessories.



Model Code	Part Number	Manufacturer	Price	Assembly Cost	Stock
M3715	9000000001	Baldor	29	5	50
DYN-CF1P350ASAE	Select				
M/P Adapter	Select				
721-20	9000000004	Parker	32	6	56
PE060R00B6B20PA00N00S1A1U	9000000005	Parker	34	4	88
P30-100	9000000006	Flow-ezy	32	6	45

Fetch Data From ERP

5. Click **Update** to update the selected row.
6. Click **Update All**, to update all the rows in the drawing.
7. Click **Cancel** to exit.

Modifying Symbols

The screenshot displays the HyDraw V700 software interface. The main window shows a hydraulic schematic with various components and connections. On the left, the 'HyDraw Library Explorer' is open, showing a 'Component Library' with 'Hydraulic Symbols' selected. On the right, the 'HyDraw Property Manager' is open, displaying the properties for a selected 'System' (V700). The 'Design requirements' section shows 'Flow' and 'Pressure'. The 'Model data' section shows 'Cost', 'Assembly Cost', 'Pressure Loss @ Rated I', 'Cavity/Footprint/Interface D08', 'Multifunction Flow(ppm)', 'Voltage 24', 'Frequency DC', 'Bolt Shoulder Height(mm)', 'Model Code D81VHW0041NJW', 'Model Family D81V', 'Description Direction Control Valve', 'Manufacturer Parker', 'Part Number PH45638', 'List Price', 'Rated Flow(ppm)', 'Rated Pressure(psi)', 'Installation Torque (Alum)', and 'Installation Torque (Steel)'. The 'Accessories', 'Documents', and 'CAD Files' sections are also visible.


28 Aligning Symbols
29 Rotating Symbols
30 Flipping Symbols
31 Aligning Symbol Ports
32 Aligning System Port Names
33 Editing Port Name
34 Editing in Place
35 Editing Solenoid Information
36 Changing Text Height
37 Rotating Property Text
38 Unlocking Position
39 Unlocking Size
40 Relocating Symbol
41 Constraining/Unconstraining Symbols
42 Stacking Symbols
43 Reassigning Item ID
44 Updating Balloons

28. Aligning Symbols

Align one symbol with another symbol, horizontally or vertically, from left, right, or middle.


1. Select the symbols you need to align.
2. Click **Align Symbols**  on the HyDraw® V700 ribbon menu.

The *Align Symbols* dialog box displays.




Align Symbols dialog box

3. Click , , or  on the Horizontal pane to align symbols horizontally from left, middle, or right.
Or,
Click , , or  on the Vertical pane to align symbols vertically from top, middle, or bottom.
4. Click **OK** to align the symbol.



Symbols aligned horizontally from left



Symbols aligned vertically from top left


29. Rotating Symbols

Rotate a symbol, 90 degrees to its left or right. The associated text is constrained to remain horizontal.


Rotate Left

1. Select the symbol you want to rotate.
2. Click **Rotate Left**  on the HyDraw® V700 ribbon menu.
or
Select **Rotate > Left** from the context menu.

The symbol rotates 90 degrees to its left.



Select a symbol




Rotate symbol to the left

Rotate Right

1. Select the symbol you want to rotate.
2. Click **Rotate Right**  on the HyDraw® V700 ribbon menu.
or
Select **Rotate > Right** from the context menu.

The symbol rotates 90 degrees to its right.



Rotate symbol to the right



30. Flipping Symbols

Flip a symbol horizontally or vertically. The associated text is constrained to remain horizontal.

Flip Horizontal

1. Select the symbol you want to flip.
 2. Click  **Flip Horizontal** from the Modify Symbol option on the HyDraw® V700 ribbon menu.
- or
3. Select **Flip > Horizontal** from the context menu.

The symbol flips horizontally.




Symbol inserted in the drawing
horizontal

Flipping the symbol

Flip Vertical

1. Select the symbol you want to flip.
 2. Click  **Flip Vertical** from the Modify Symbol option on the HyDraw® V700 ribbon menu.
- or
1. Select **Flip > Vertical** from the context menu.
 2. The symbol flips vertically.




Flipping the symbol vertical

31. Aligning Symbol Ports


Align ports of different symbols horizontally or vertically.

1. Click **Align Symbol Ports**  on the HyDraw® V700 ribbon menu.
3. Click the **Symbol to move** button in the Select pane to select the symbol you need to align.
4. Click **Next Port**, if you don't want to align this port and another port.
5. Click the **Symbol to align with** button in the Select pane to select the other symbol, which you need to align it with.

A red dot appears along the port to be aligned.



Align symbol ports menu



Align Symbol Ports dialog box


A red dot appears along the port to be aligned.

6. Click **Next Port**, if you don't want to align this port and another port.
7. Click  in the Alignment pane to align ports horizontally, Or
8. Click  in the Alignment pane to align ports vertically.


The symbols are aligned with reference to their ports.

Note

When you align symbols, the first symbol gets constrained to the second symbol and moves with it till you manually relocate the first symbol.



Symbol ports aligned vertically




Symbol ports aligned horizontally

32. Aligning System Port Names


Align port names of all the selected ports horizontally or vertically.

1. Select the system ports, which names you need to align.
2. Click **Align System Port Names**  on the HyDraw® V700 ribbon menu.


In the given selection, the left and bottom port name is taken as reference and all other system port names are aligned in a single line parallel to the envelope.



Align submenu



Selected system ports



System port names aligned


33. Editing Port Name

Edit the port name or the other name of the selected symbol in the drawing. This does not affect the master symbol in the HyDraw® library.


1. Select the symbol to edit its port name.
2. Click **Edit > Port** on the HyDraw V700 ribbon menu.
The Edit Port dialog box displays.
3. Type the new name in the **Name** column and the optional **Other name**.
3. To delete the port, click .
4. Select **Name/Other name** in the Display option. .
5. Click **OK**.

The Name/Other name of the port displays with the symbol.

If both the names are selected, then dual port names are displayed.




Edit submenu




Edit Port dialog box

Note

Changes affect only the symbol in the drawing and not the master symbol in the HyDraw Library.



Symbol with unedited ports



Symbol with Name and Other name


34. Editing in Place

Edit the selected symbol in the drawing. It does not affect the master symbol in the HyDraw® library.


1. Select a valid HyDraw symbol.
2. Click **Edit symbol**  on the HyDraw V700 ribbon menu
The Symbol stencil opens for edit.
3. Use Visio > Home > **Tools**
or
The drawing commands to draw and edit the symbol.
4. Close the window after you make the changes.

Note

Changes affect only the symbol in the drawing and not the master symbol in the HyDraw Library.



Opened symbol stencil for edit



Symbol after edit


35. Editing Solenoid Information

Edit the Solenoid ID of the selected symbol and Function in the drawing. It does not affect the master symbol in the HyDraw® library.


1. Select a valid HyDraw symbol.
2. Click **Edit Solenoid Info**  **Edit Solenoid Info** on the HyDraw V700 ribbon menu
The Symbol stencil opens for Edit Solenoid Information.
3. In the Solenoid ID column, edit the ID, if already available, or enter a new ID.
The Show check box changes the visibility of the ID and Function for the selected symbol.
4. In the Available Functions section, enter the Function name and click the **Add** button.
*The **Update** button allows editing the existing function.*
5. Select the **solenoid name**.
6. Select the **function**.
7. Click the **Add selected function** button.
The selected function is added to the selected solenoid name.
8. Click **OK** to close the window and to make changes.

Note


Changes affect only the symbol in the drawing and not the master symbol in the HyDraw Library.



Opened symbol stencil for edit



Symbol before edit




Symbol after edit


36. Changing Text Height

Change the text height of the displayed Item ID and other parameters of the selected symbols.

1. Select the symbol to change its text height.
2. Click **Change Text Height** on the HyDraw® V700 ribbon menu.




The Change Text Height dialog box displays.



Change text height dialog box

3. Enter the new text height.
4. Select **Update Item ID** to change the item ID text height.
5. Select **Update property text** to change the text height of the displayed parameters.
6. Click **OK**.

The height of the text is changed.




Text height changed (Before and After)


37. Rotating Property Text

Rotate the text properties of the selected symbol, external port, and connection line.

1. Select the symbol/external port/connection line to rotate its property text.
Click **Rotate Property Text** on the HyDraw® V700 ribbon menu.



The Rotate Property Text dialog box displays.



Rotate Property Text dialog box

2. Select the property you want to rotate.

3. Click **Rotate Left** 


The Property Text rotates 90 degrees to its left.

4. Click **Rotate Right** 


The Property Text rotates 90 degrees to its right.

5. Click **OK**.


The property of the text is rotated.



Symbol – Property text rotated



External Port - Property text rotated



Connection Lines – Property text rotated

38. Unlocking Position

Lock the position of a symbol to prevent its inadvertent movement.
Move the symbol to a different position after unlocking it.

Lock Position

1. Select the symbol to lock its position.
2. Click **Position**  from the (Un)Lock option on the HyDraw® V700 ribbon menu.

The symbol gets locked at its current position.

A lock image  displays at the left bottom corner of the symbol.

Unlock Position

1. Select the symbol that is locked or the symbol you want to unlock.
2. Click **Position**  from the (Un) Lock option on the HyDrawV700 ribbon menu.

Alternatively, click  on the HyDraw V700 ribbon menu.


The lock image disappears.

Move Symbol


You can move a symbol in the schematic from one location to another, while retaining its connections.

1. Select the symbol (position unlocked) you want to move.
 2. Drag it to the desired location.
- Alternatively,
Use arrow keys on the keyboard to move it left, right, up, or down.


The symbol is moved to the new location, while retaining its connections.



Symbol in locked position



Symbol selected for repositioning




Symbol moved to new location: retaining connections

39. Unlocking Size

Prevent inadvertent increase or decrease of the original size of the symbol by locking it. All symbols are locked when inserted into the drawing. Use the (Un)Lock command to unlock and then change the symbol size.

Lock Size


1. Select the symbol to lock its size.
2. Click **Size**  from the (Un)Lock option on the HyDraw® V700 ribbon menu.
The size of the symbol gets locked. Small black color filled squares appear at the corners and middle of the boundary box of the symbol.



Symbol size locked

Unlock Size

1. Select the symbol to unlock its size.
2. Click **Size**  from the (Un)Lock option on the HyDraw V700 ribbon menu. Alternatively, Click  on the HyDraw V700 ribbon menu.
The small black color filled squares change to blue.



Resizing the symbol

Resize Symbol

1. Select the symbol (size unlocked) in the drawing to resize it.
The resize shape option appears automatically, when the cursor is close to the boundary box corner points.
2. Drag it to the required size.

Note

- The symbol size gets automatically locked when you drag and drop a symbol from the library to the drawing.
- Always resize the symbol from the corner point of the boundary box and do not resize from the middle point.

40. Relocating Symbol

Position a symbol relative to another symbol in the drawing by taking the port as reference.

1. Select the symbol to relocate.
2. Click **Relocate**  **Relocate** on the HyDraw® V700 ribbon menu.
or
Alternatively select **Relocate** from the context menu.

The Relocate Symbol dialog box displays.

The selected symbol is encircled with a green envelope and a red dot on the first inserted port.

This port reference can be changed by clicking the **Next Port**.



3. Select **Reference symbol**.
The selected symbol is encircled with the red envelope and displays X, Y co-ordinates with the red dot on the first inserted port.

This port reference can be changed by clicking the **Next Port**.



The coordinates in the dialog box display the location of the symbol to be moved (green envelope) with respect to the selected reference port.

4. Specify the new X and Y location.
5. Click **OK**.

The green envelope symbol moves to the specified X and Y location with reference to the red enveloped symbol.



Relocate Symbol




Relocate Symbol with X at Zero

41. Constraining/UnConstraining Symbols

The *Constrain* command enables you to constrain symbols to another symbol of the selected symbols in the drawing.
The *UnConstrain* command enables you to remove constrains of the selected symbols.

Constrain


1. Select the symbols to constrain.
2. Click **Constrain**  **Constrain** on the HyDraw® V700 ribbon menu.
The Constrain symbols dialog box displays.
All the selected symbols are encircled with a green envelope.
3. Select **Symbol to constrain with**.
The selected symbol is encircled with a red envelope.
4. Click **OK** to constrain the symbols to another symbol.
All the constrained symbols show the constrained sign .



Constrain Symbols

UnConstrain

1. Select the constrained symbols in the drawing.
2. Click **UnConstrain**  **UnConstrain** on the HyDraw V700 ribbon menu.
All the constrained symbols are unconstrained.



Symbols Constrained

Note

Constrained symbols cannot be moved or relocated independently.
When the "symbol to constrain with" is moved, the constrained symbols move with it.

42. Stacking Symbols

Stack the symbols horizontally or vertically.


1. Select the symbols to stack.
2. Click **Stack**  on the HyDraw® V700 ribbon menu.

The Create Stack dialog box displays.


3. Click  or  top or bottom symbol to move the stack.
4. Click  or  left or right symbol to move the stack.
5. Click **OK** to stack the symbols.

Note

- Port 'P' is the default alignment guide.
- If there is no 'P' port, then port 'X' is used (e.g. Slip-in cover).
In all other cases, Symbol Alignment box center is used to align the symbols.
- Move the stack by holding the symbol without the constrain image.
- Selecting the symbol and clicking the  UnConstrain sign, removes the constrains.



Symbols to Stack




Create Stack

43. Reassigning Item ID

Reassign the Item IDs of all symbols in the circuit after modification.

1. Click **Reassign Item ID** on the HyDraw® V700 ribbon menu.
3. Alternatively,
Click  **Item ID** on the HyDraw V700 ribbon menu.
The Reassign Item ID dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Enter the starting value of the item ID.
4. Enter the **Assembly ID**.
5. Choose the **Balloon** shape.
Select the checkbox, if you want to use the current balloon type.
6. Select the appropriate option for **Items included**.
 - Select the **Components** checkbox to include all components.
 - Select the **Component accessories** checkbox to include all component accessories.
 - Select the **System accessories** checkbox to include all system accessories.
7. Click **Update**.



Reassign Item ID


44. Updating Balloons

Update balloons of selected symbols or schematic. The update affects both numbering scheme and type of balloons.

1. Click **Update Balloon** on the HyDraw® V700 ribbon menu.
Alternatively,
Click  on the HyDraw V700 toolbar.


The Update Balloon dialog box displays.

2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the required balloon style or select the current balloon type.
4. Click **OK**.



Update Balloon dialog box

Parts List and more




45. Creating and Inserting Parts List

Create a list of components and accessories for a schematic.

Insert Parts List


1. Click **Parts**  on the HyDraw® V700 ribbon menu.
The Create Parts List dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the items to be included,
 - Select the **Components** checkbox to include all components in the Parts list.
 - Select the **Component accessories** checkbox to include all component accessories in the Parts list.
 - Select the **System accessories** checkbox to include all system accessories in the Parts list.
 - Select the **Group identical items** checkbox to group all the identical items in the Parts list.

Group identical items works only for 1A, 1B, 2A, 2B..., 1.1,1.2,2.1,2.2..., and 1-1,1-2,2-1,2-2... numbering scheme.
4. Select the required **Format**.
The default format is applied, if nothing is selected.
5. Click **Next** to display the Parts List dialog box.
The Create Parts List dialog box displays detail of the Parts properties.




Create Parts List dialog box

6. Click  or  to move the selected item one row up or one row down, respectively.
7. Click  to delete the selected item from the list.
8. Click **Insert to Drawing** to insert the Parts list as a separate list in the drawing.
A message box displays and notifies to specify a rectangular area to insert the Parts List.
9. Select a rectangular area in the drawing to insert the Parts list.
The Parts list is inserted into the Visio drawing in a tabular form.
10. To save the Parts list as an Excel sheet, click **Export to Excel**.
The Parts List is saved in the Excel format.



Create Parts List dialog box



Create Parts List message box

Item ID	QTY	Model Code	Description	Manufacturer
1	1		Envelope	
2	1	RV10-10**	Direct Acting Pressure Relief Valve	Eaton
3	1	CB101**	Counterbalance Valve	Parker
4	1	GS0454D-**	3/4 Way Solenoid Operated Direction Control Valve	Parker
5	1	D1WV5	DS Coil , 1/2", 5/8" I.D.	Anchor Flange
6	1	J06A2-**	Needle Valve	Parker
7	1	D1WV1	1/2? Solenoid Tubes	Donaldson
8	1	D1WV2	DS Coil , 1/2", 5/8", 1" I.D.	Command Controls
9	1	D1WV3	DS Coil , 1/2", 5/8", 1" I.D.	Bucher Hydraulics

Parts List

Customize Parts List Format

1. Select **Options...** on the HyDraw® V700 ribbon menu.
2. Click the **Parts List** tab.

The Parts List formatting box displays inside the tab.

3. To rename a selected format, type the new name in the text box and click .

4. To add a new format, type the new name in the text box and click .

5. To delete a selected format, click .

*The **Configure Columns** section enables to edit Display Name, Alignment, and Width of the columns.*

6. Click **Select Columns**.
The Select Parts List Columns dialog box displays.


7. Select the required Model properties or Design requirements checkbox.

8. Set the Start Column and the Start Row of the Parts List to be inserted into the Excel template.


9. Click **OK**.

The properties of the selected item are displayed in the Parts List formatting box in the Configure columns section.

The same properties are displayed in the tabular form Parts list, when creating Parts list in the Visio drawing.



HyDraw Options: Parts List




Select Parts List Columns dialog box

46. Creating and Inserting Ports List


Create a list of external ports used in the circuit and insert this list in the drawing. The tabular list exhibits details about the external ports.

Insert Ports List


1. Click **Ports**  on the HyDraw® V700 ribbon menu.
The Create Ports List dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the **Group identical items** checkbox to group all identical items in the Ports list.
Group identical items works only for 1A, 1B, 2A, 2B..., 1.1,1.2,2.1,2.2..., and 1-1,1-2,2-1,2-2... numbering scheme.
4. Select the required **Format**. If no format is selected, then the default format is applied.
5. Click **Next** to display the Ports List dialog box.
The Create Ports List dialog box displays the detail of the port properties.
6. Click  or  to move the selected item one row up or one row down, respectively.
7. Click  to delete the selected port from the list.
8. Click **Insert to Drawing** to insert the Ports list as a separate list in the drawing.
A message box notifies to specify a rectangular area to insert the Ports list.
9. Select a rectangular area in the drawing to insert the Ports list.
The Ports list is inserted into the Visio drawing in a tabular form.



Create Ports List dialog box



Create Ports List



Create Ports List message box

Customize Ports List Format

1. Select **Options...** on the HyDraw® V700 ribbon menu.
2. Click the **Ports List** tab.

The Ports list formatting box displays inside the tab.

3. To rename a selected format, type the new name in the textbox and click .

4. To add a new format, type the new name in the textbox and click .

5. To delete a selected format, click .

*The **Configure Columns** section enables you to edit Display Name, Alignment, and Width of the columns.*

6. Click **Select Columns**.


The Select Ports List columns dialog box displays.

7. Select the required checkboxes.


8. Click **OK**.

The properties of the selected item are displayed in the Ports List formatting box in the Configure columns section.

The same properties are displayed in the tabular form Ports list, when creating the Ports list in the Visio drawing.



Ports List tab




Select Ports List columns


47. Creating and Inserting Net List

Create a list of networks (Net List) of components and external ports in the circuit and insert the Net list in the drawing.
The tabular list exhibits details about the networks.

1. Click **Net** on the HyDraw® V700 ribbon menu.
The *Create Net List dialog box displays.*
2. Select one of the two options,
 - Click the **Active page** button to select the drawing in the active page.
 - Click the **Selected symbols and connections** button to select specified component symbols.
3. Click **OK**.
The *Create Net List box displays net name with corresponding net items and status.*



Create Net List dialog box



Create Net List

The *Status* column shows the accounted nets with  and amended nets with  indicating that the nets are amended and require recreation.

By selecting a net on the *Status* column, the respective net is highlighted in the *Visio* drawing. (If the connection is not correct, red dots appear along the connection points.)

4. Click **Clear Error Flags** to rectify a connection.
5. Click **Recreate** to return to create the Net list.
6. Click **Export to Excel** to save the Net list as an Excel file (.xls/xlsx).
7. Click **Insert to Drawing** to insert the Net list or Click **OK** to save the Net list and exit.

Note:

The individual symbols of Slip-Cartridge valve cover and Insert are combined with “&” and treated as a single entity, when creating the Net list.


Caution:

- Do not create more than one connection to the connection points. This may result in an incorrect Net list.
- If **OK** is not pressed after net renaming, the corrections will be lost on recreation, with default net naming style.

48. Creating and Inserting Solenoid Actuation Chart

Create Solenoid Actuation Chart and insert it in the drawing.

1. Click **Solenoid**  on the HyDraw® V700 ribbon menu.
The Solenoid Actuation Chart dialog box displays.
2. Select one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Under grouping select the **Use Item ID** option.
4. Click **Next**.
The Solenoid Actuation Chart displays Function, Item ID-Solenoid ID, if applicable.
5. Click **Back** to change the selection.
6. Click the **Update**  button to update the function name.
7. Click  or  to move the selected item one row up or one row down, respectively.
8. Click  to delete the selected port from the list.
9. Click **Export to Excel** to save the Solenoid Actuation Chart as an Excel file (.xls/xlsx).
10. Click **Insert to Drawing** to insert the Solenoid Actuation Chart into the drawing.



Solenoid Actuation Chart – Selection



Solenoid Actuation Chart – Grid View


FUNCTION	0V3-S1	0V3-S2	0V7-S1	0V7-S2
Cylinder Up	●	○	○	○
Cylinder Down	○	●	○	○
Cylinder Ext.	○	○	●	○
Cylinder Ret.	○	○	○	●

Solenoid Actuation Chart


49. Showing/Hiding Port Names

Show or hide port names of the selected symbols in the drawing.

1. Select the symbol to show or hide the port names.
2. Click **Show**  Show on the HyDraw® V700 ribbon menu.
The port names for the selected symbol are displayed.
3. Click **Hide**  Hide on the HyDraw V700 ribbon menu.
The port names for the selected symbol are hidden.



Port names displayed




Port names hidden

50. Display Settings

Display or hide the property values of the components, external ports, and connections, per the Show/Hide property selection in the schematic drawing.

1. Click  **Display Settings** from the Properties group on the HyDraw® V700 ribbon menu.
The Display Settings – Selection dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.




Display Settings

The Display Settings – Property dialog box displays.

3. Click the appropriate checkbox to select individual properties of components, external ports, or connections.
4. Click **OK**.

Note

The **Back** option takes you to the previous dialog box.




Components with properties shown and hidden

51. Purging Price Data


Remove price information from components in the schematic drawing.

1. Select the components of the schematic for which you want to remove the price information.
2. Click **Purge Price Data** on the HyDraw® V700 ribbon menu.
The components in the schematic are selected automatically.

The Purge Price Data warning message box displays, indicating that the price data will be removed permanently from the selected components on the drawing.
3. Click **OK**, if you want to continue.
On completion, prompts a message - Price data removed successfully.
4. Click **OK**.



Purge Price Data warning box



Purge Price Data message box

Note

Save the schematic with a different file name and/or location before removing price information for your convenience and future reference.

52. Purging Properties

Remove the information of the selected properties from the components, component accessories, and system accessories in the schematic drawing.

1. Click  from the Properties group, on the HyDraw® V700 ribbon menu.

The Purge Properties – Selection dialog box appears.

2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the items to be included,
 - Select the **Components** checkbox to include all components for purge properties.
 - Select the **Component accessories** checkbox to include all component accessories for purge properties.
 - Select the **System accessories** checkbox to include all system accessories for purge properties.


4. Click **Next**.

The Purge Properties – Property dialog box displays.

5. Click the checkbox to select individual properties or click **Select All** properties to remove the data.
6. Click **OK**.

The Purge properties progress bar appears and on completion, displays the message, 'Selected data removed successfully'.

7. Click **OK**.




Purge Properties dialog box

Warning:


The data once purged is lost forever and cannot be recovered using Visio Undo command.

Note:


The **Back** button takes to the previous dialog box.



Purge Properties completion



HyDraw Property Manager before purge properties



HyDraw Property Manager after purge properties

53. Display Format

Add new display formats to the symbols.

1. Click  **Display Format** on the HyDraw® V700 ribbon menu.

The Add New Display Format – selection dialog box displays.

2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.

3. Click **OK**.

The Add New Display Format dialog box displays.


4. Enter the **Name** of the display format.
5. Click  on Property1 section to select the property to display in required format.

The Select Property dialog box displays.


6. Select property and click **OK**.
7. Enter the prefix and suffix values to be displayed.
8. Select the Display unit check box to display the units.

Repeat steps 5 to 8 to select more than one and up to three properties to be displayed in this display format.


9. Click **Add** to add a new display format with the selected symbols.



Add New Display Format – Selection



Add New Display Format dialog box



Select Property

Collating Files

HyDraw Sample Schematic.vsdX - Visio Professional

FILE HOME INSERT DESIGN DATA PROCESS REVIEW VIEW DEVELOPER HyDraw V700

Insert More- More- Modify Symbols Properties

Relocate Align - Constrain Stack Show ERP Interface

Copy Update - Edit

Collating Documents
Collating CAD Files

Purge Purge Manifold Submit Settings Go to Unit Converter Calculator Options Help About Setup

Price QuickManifolds

54 Collating Documents
55 Collating CAD Files

ITEM ID	QTY	MODEL CODE	DESCRIPTION	MANUFACTURER	NET NAME	NET LIST S
GA1	1	8.0UJ-DH-RF4M-30.00	Cylinder Hydraulic	Parker	NET-1	OP1-B, OZ3-OUT
OV2	1	3.2SC-2HC1K1AC-12.00	Cylinder Hydraulic	Bosch Rexroth	NET-2	PR1, OP1-P
OP1	1	PE00R008B020P0A0N0001A1U	Pump Variable Single	Parker	NET-3	OZ3-OUT, TR1
OV1	1	0M141U	Needle Valve	Parker	NET-4	T, OZ8-IN
OV2	1	SPRES10P1SN	Check Valve	Parker	NET-5	OV3-T, T, OV7-T
OV3	1	DE1VH050AC1NJW	Direction Control Valve	Parker	NET-6	OZ4-I, OV1-OUT
OV4	1	ERC5M	Counterbalance Valve	Parker	NET-7	OV1-IN, G
OV5	1	FCDB-LAN	Flow Control Valve	Sull	NET-8	OV2-IN, P, G, OV2-B
OV6	1	FCDB-LAN	Flow Control Valve	Sull	NET-9	OV2-B
OV7	1	5-4V1E10E3XC624N6	Direction Control Valve	Bosch Rexroth	NET-10	OV3-P, OV2-OUT
OZ1	1	T-300-FV	Reservoir	Velsor	NET-10	OV4-S, OV3-B
OZ10	1	BR12	Fiber/Weather	Elton	NET-11	B, OV4-P
OZ2	1	M811	Strangle	COG	NET-12	A, OV3-A, OV4-PC
OZ3	1	P30-100	Suction Strainer	Flow-4zy	NET-13	TR1
OZ4	1	G300	Pressure Gauge	Stauff	NET-14	OV2-Y, DR
OZ5	1	D25M3AEB	Motor/Pump Adapter	BSP	NET-15	OP1-DR
OZ6	1	400-M65-B8	Coupling Set	Magnatray	NET-16	DRR1
OZ7	1	725-020	Hose	Parker	NET-17	DR, DRR1
OZ8	1	50AS105QBP0G20	Filter	Parker	NET-18	OZ9-I, LVL
OZ9	1	LS167	Flot & Temperature Switch	Gema	NET-19	OZ10-I, BR

ITEM ID	PORT SIZE	DESCRIPTION
K.T. TR1	2 1/2-11	1-1/2 BSP
B. LVL, P	2 1/4-11	1-1/4 BSP
A2, B2, BR	Q 1/2-14	1/2 BSP
DR, DRR1, G	Q 1/4-19	1/4 BSP

FUNCTION	OV3-S1	OV3-S2	OV7-S1	OV7-S2
PITCH CYL EXTEND	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
PITCH CYL RETRACT	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
ROLL CYL EXTEND	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
ROLL CYL RETRACT	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

DESCRIPTION: VEST HyDraw Schematic
3280 W. Big Beaver Road, Suite 440, Troy, MI 48064 USA
www.VESTusa.com

Page-1 | Page-2 | All | +


PAGE 1 OF 2 WIDTH: 1.732 IN. HEIGHT: 0.63 IN. ANGLE: 0° ENGLISH (UNITED STATES)

68%


54. Collating Documents

Save the documents linked to components, component accessories, and system accessories in the user-specified location.

1. Click **Collate Documents**  on the HyDraw® V700 ribbon menu.
The Collate Documents dialog box displays.
2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.
3. Select the items to be included,
 - Select the **Components** checkbox to collate the documents linked with the components.
 - Select the **Component accessories** checkbox to collate the documents linked with the component accessories.
 - Select the **System accessories** checkbox to collate the documents linked with the system accessories.
4. Click **Next** to display the Collate Documents dialog box showing linked files.
The Collate Documents dialog box displays.
5. Select the files and click **OK** to save the documents in the appropriate folder.
The Browse For Folder dialog box displays.
6. Select the appropriate folder or click **Make New Folder** to create a new folder in the appropriate location to save the documents.



Collate Documents dialog box



Collate Documents: save files

55. Collating CAD Files

Save the CAD files linked to the component, component accessories, and system accessories in the user-specified location.

1. Click **Collate CAD Files** from the Collate option on the HyDraw® V700 ribbon menu.

The Collate CAD Files dialog box displays.

2. Select any one of the three options,
 - Click the **Active page** button to select the drawing in the Active page.
 - Click the **All pages** button to select the whole document in the file.
 - Click the **Selected symbols** button to select the specified component symbols.

3. Select the items to be included,
 - Select the **Components** checkbox to collate the documents linked with the components.
 - Select the **Component accessories** checkbox to collate the documents linked with the component accessories.
 - Select the **System accessories** checkbox to collate the documents linked with the system accessories.


4. Click **Next** to display the Collate CAD Files dialog box showing linked files.

The Collate CAD Files dialog box displays.


5. Select the files and click **OK** to save the documents in the appropriate folder.

The Browse For Folder dialog box displays.

6. Select the appropriate folder or click **Make New Folder** to create a new folder in the appropriate location to save the documents.



Collate CAD Files dialog box



Collate CAD Files: Save Files

Manifold Quote

Demonstration Manifolds Inc.

Demo Street, Suite 440
 Troy, MI, United States
 Phone: (248) 649-7663
 Fax:

Quotation

Quotation No:
 Date: June 24, 2012

56 Manifold Quote

Quotation To:

Ian Russel
 Price Engg
 United States
 Ph: 113241234
 ian.russel@priceengg.com

Customer Part No: Demo Circuit V600
 Prepared By: James Dean
 E-Mail: manufacturer@vestusa.com

Quotation Details:

Date of Request:	June 24, 2012	
Quote Valid Upto:	July 13, 2012	

Design

Design Charges:	338	USD
Taxes on Design Charges:		
Total Design Charges:	338	USD
Design Delivery Business Days:	12	

Manufacturing

Quote Quantity:	1	
Price for Manufacturing Quote Quantity:	1296	USD
Plus Taxes:		
Total Manufacturing Charges:	1296	USD
Delivery Location:	FOB Manufacturer	
Delivery Business Days:	5	

Item Summary:

Block Details		
Block Volume:	8734141.24	Cubic Millimeter
Block Weight:	68.48	kg
Block Material:	Steel (Weldable)	
Plating:	No Plating	

Cavity/Port	Quantity
D08	1
C1025	1
T-5A	2
D05	1
G 1 1/2 -11	2
G 1/2-14	2
G 1 1/4 -11	2
G 1/4-19	2

56. Manifold Quote


Request a manifold quotation from a registered manifold manufacturer.

1. Click **Manifold Quote** from the Manifold Quote option on the HyDraw® V700 ribbon menu.
The Manifold Quote dialog box displays.
2. Click the **Active page** button to select the drawing in the Active Page. (or)
Click the **Selected symbols** button to select specified component symbols.
3. Click **OK** to continue.
The Manifold Quote dialog box displays.
4. Select the manufacturer, material and plating, delivery details, and the order quantity.
5. Click **Check Manufacturability**.
The Check Manufacturability dialog box displays.


 sign in the Manufacturable column shows that the cavity is available and  sign shows the cavity is not available.

6. Click **Assign Cavity** to assign the cavity, where the cavity is not available
The Assign cavity dialog box displays.
7. Click **Submit**.
When the manifold quote request is submitted a successful message box displays.


The quotation will be mailed to the respective user mail ID.




Manifold Quote dialog box



Manifold Quote dialog box



Check Manufacturability dialog box



Assign Cavity dialog box

MDTools Interface

HyDraw Sample Schematic.vsdw - Visio Professional

FILE HOME INSERT DESIGN DATA PROCESS REVIEW VIEW DEVELOPER HyDraw V700

Insert More More Modify Symbols Properties

Copy Update ERP Interface

Balloon Item ID Display Settings Display Format

Parts Net Solenoid

Purge Purge Settings Unit Converter QuickManifolds

Options Help About Setup

57 Exporting to MDTools

ITEM ID	QTY	MODEL CODE	DESCRIPTION	MANUFACTURER	NET NAME	NET LISTS
CA1	1	S 00J-2HURF45A-30.00	Cylinder Hydraulic	Parker	NET-1	OP1-S, OZ3-OUT
CA2	1	S 00C-2HURF45A-12.00	Cylinder Hydraulic	Parker	NET-2	PR1, OP1-P
OP1	1	PECORP080502PAC000	Electric Motor	BUSCH	NET-3	OZ3-OUT, TR1
OP1	1	05A1414	Pump Variable Single	Parker	NET-4	T, OZ3-IN
OV1	1	05A1414	Needle Valve	Parker	NET-5	OV3-T, OV7-T
OV2	1	SPRES10P15N	Check Valve	Parker	NET-6	OZ4-1, OV7-OUT
OV3	1	05V1050AC-1N1N	Direction Control Valve	Parker	NET-7	OV7-IN, G
OV4	1	BRC2M4	Counterbalance Valve	Parker	NET-8	OV2-IN, P, G, OV7-P
OV5	1	FDCB-LAN	Flow Control Valve	Sun	NET-9	OV3-P, OV2-OUT
OV6	1	FDCB-LAN	Flow Control Valve	Sun	NET-10	OV4-S, OV2-B
OV7	1	4-0V81053X-C524N9	Direction Control Valve	Recon Rexroth	NET-11	B, OV4-P
OZ1	1	T-300-PV	Reservoir	Wessco	NET-12	A, OV3-A, OV4-R
OZ10	1	BR12	Filter/Breather	Edson	NET-13	TR1
OZ2	1	MM1	Strainer	CDC	NET-14	OV3-Y, DR
OZ3	1	93K-100	Swivel Strainer	Flow-Ko	NET-15	OP1-D
OZ4	1	G300	Pressure Gauge	Stauff	NET-16	DRR1
OZ5	1	D225M/SAEB	Motor/Pump Adapter	BSF	NET-17	DR, DRR1
OZ6	1	500-850-88	Coupling Set	Magnatrol	NET-18	OZ5-1, LVL, BR
OZ7	1	71-50	hose	Parker	NET-19	R2, OV6-2
OZ8	1	50A5105GEBPGG20	Filter	Parker	NET-20	OV5-1, OV7-B
OZ9	1	LS167	Flg & Temperature Switch	demu	NET-21	OV6-1, OV7-B
					NET-22	A3, OV5-2
					NET-23	OV5-1, OV7-A
					NET-24	P, Z3-T
					NET-25	OZ7-1, PR1
					NET-26	A, OA1-1
					NET-27	B, OA1-2
					NET-28	A2, OA2-1
					NET-29	B2, OA2-2

ITEM ID	PORT SIZE	DESCRIPTION
A, T, NET	G 1 1/2-11	1-1/2 BSP
B, LVL, P, PR1	G 1 1/4-11	1-1/4 BSP
A2, B2, BR	G 1/2-14	1/2 BSP
DR, DRR1, G	G 1/4-15	1/4 BSP

FUNCTION	OV3-51	OV3-52	OV7-51	OV7-52
PITCH CYL EXTEND	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
PITCH CYL RETRACT	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
ROLL CYL EXTEND	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
ROLL CYL RETRACT	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

DESCRIPTION
VEST HyDraw Schematic
3280 W. Big Beaver Road, Suite 440, Troy, MI 48064 USA
www.VESTusa.com

Page-1 | Page-2 | All

PAGE 1 OF 2 WIDTH: 1.732 IN. HEIGHT: 0.63 IN. ANGLE: 0° ENGLISH (UNITED STATES)


68%

57. Exporting To MDTools


Export a HyDraw® V700 created circuit as an XML, which can be readily opened in MDTools® for designing a manifold.

1. Click **Export To MDTools** on the HyDraw V700 ribbon menu.
The Export to MDTools dialog box displays.
2. Click the **Active page** button to select the drawing in the Active page.
4. Or
5. Click the **Selected symbols and connections** button to select the specified component symbols.
3. Click **OK** to continue.
The Save As dialog box displays.


Save the resulting XML file at the desired location.



Export to MDTools sub-menu



Export to MDTools dialog box



Save As dialog box for XML

Using QuickManifolds.com

58 Introduction to QuickManifolds

59 Go To QuickManifolds.com

60 Submit Circuit to QuickManifolds

61 Check Design Status

62 QuickManifolds Viewer

63 Purging QuickManifolds Data

QUICK MANIFOLDS.COM

Contact Us | Request a Web Demo | Sign Up | Login

Started About Us

Trial

Design as many Manifolds as you want
Free for a Month

Start Now >

Replay

Setup Input Output Compatibility Limitations Requirements

Fully automated manifold design

No more design backlogs

QuickManifolds® is a fully automated manifold design service, powered by VEST patented AutoRouter™ technology*. The service is web enabled and available on demand

* US Patent No 7558713

Submit your hydraulic circuit, and QuickManifolds will deliver your manifold design 3D CAD model and manufacturing drawings within minutes at a cost that is significantly lower than standard design processes

58. Introduction to QuickManifolds

The www.QuickManifolds.com is promoted by VEST, Inc. the leader in manifold design software. It can automatically create an error free compact manifold for an input hydraulic schematic drawing.

QuickManifolds® is an online automated manifold design service, powered by VEST patented AutoRouter™ technology*.

The service is available 24x7 at www.QuickManifolds.com

The process starts with a hydraulic circuit and the software generates a complete manifold design.

The AutoRouter™ program automatically places all cavities on the block, creates hydraulic connections between cavities, per the schematic drawing.

The program also does the required design checking.

Each assignment submitted to QuickManifolds® can take a couple of seconds to 3 -4 hours to design the manifold.

The time taken depends on the number of cavities, connection complexity, and the constraints applied.


** US Patent No. 7558713*

59. Go To QuickManifolds.com

You are directed to the www.QuickManifolds.com website.

Click **Go to**  on the ribbon menu

The *QuickManifolds* portal opens:
www.QuickManifolds.com



The screenshot displays the QuickManifolds.com website interface. At the top, there is a navigation bar with buttons for "Home", "Benefits", "Getting Started", and "About Us". Below the navigation bar is a large diagram of a hydraulic manifold design. The diagram shows a complex network of pipes and valves, with various components labeled such as "T-11A", "1B", "A", "B", "X", "Y", "P", "T", and "ISO4401-05-05". The diagram is color-coded with red, blue, and green lines. Below the diagram, there is a section titled "Fully automated manifold design" with the subtitle "No more design backlogs". This section contains two columns of text: "QuickManifolds® is a fully automated manifold design service, powered by VEST patented AutoRouter™ technology* The service is web enabled and available on demand" and "Submit your hydraulic circuit, and QuickManifolds will deliver your manifold design 3D CAD model and manufacturing drawings within minutes at a cost that is significantly lower than standard design processes". At the bottom of the page, there is a small note: "*US Patent No. 7555713".


QuickManifolds.com

60. Submitting Circuit to QuickManifolds

Submit HyDraw® schematics to QuickManifolds® for automated manifold design.

1. Click **Submit Circuit** from the Submit drop-down menu on the HyDraw V700 ribbon menu.


The QuickManifolds: Login dialog box displays.




Submit: Submit Circuit

2. Enter your user name and password.
The Submit Circuit dialog box displays.
3. Click the **Active Page** button to select the entire page. (or)

Click the **Selected symbols** to submit only the selected components and ports.



QuickManifolds: Login



Submit Circuit – Selection dialog box

The QuickManifolds: Submit Design page loads.

The data and the default values entered into HyDraw® are automatically read from the QuickManifolds® Web server and populated into the user interface.

The QuickManifolds: Submit Design page has 4 property tabs: Geometry, Design, Constraints, and Submit.

Geometry Tab

- The Geometry tab consists of three sections, Component, External Port, and Orifice.
- The **Component** section displays ID, Model, Cavity, Outline, Stamp, and Available status of the cavity.
- Select the Footprint/Cavity and Click **Assign Outline** that enables to redefine the component outline.
For Cavities – Select the Use Spot Face Diameter or Custom and define the diameter.

Item ID	Model	Cavity	Outline	Stamp	Available
4	CXDA	T-13A	31.75	5	✓
5A	RDDA	T-10A	31.75	2	✓
5B	RDDA	T-10A	31.75	3	✓
6	D1V	D03	150*55	1	✓

Port	Cavity	Outline	Stamp	Available
A	#8 SAE	30.18	A	✓
B	#8 SAE	30.18	B	✓
G	#4 SAE	21.03	G	✓
P	#8 SAE	30.18	P	✓
T	#8 SAE	30.18	T	✓

QuickManifolds: Submit Design- Geometry


Use Spot Face Diameter
 Available Outlines

Manufacturer: _____
Eaton
Model Family: _____
SP-10C
Outlines: _____


Custom Outline
Diameter: _____

OK Cancel


Cavity – Assign Outline



Footprint - Assign Outline : Same as FootprintEnvelope



Footprint - Assign Outline : Available outline



Footprint - Assign Outline : Custom


For Footprint - Select Custom Outline and define L, W, X and Y as described in the Preview.

- For Footprint - Select the Same as Footprint Envelope or Custom Outline and define L, W, X and Y as described in the Preview.
- Select the Footprint/Cavity and Click **Assign Cavity** that enables to reassign the cavity.

By default only the Footprints/cavities with the same number of ports are displayed.

*To view all cavities irrespective of the number of ports of the Footprints/Cavity, select **Show All Cavities**.*

- The **External Port** section displays ID, Model, Cavity, Outline, Stamp, and Available status of the cavity.
- The Assign Outline option enables to redefine the outline of the ports.
- The Assign Cavity option enables to reassign the cavity for the ports.
- The **Orifice** section displays Orifice, Cavity, Outline, Stamp, and Available status of the cavity.
- The Assign Cavity option enables to reassign the cavity for the orifices.



Assign Cavity

Design Tab

1. Configure following settings,
 - Design Units
 - Mounting Holes
 - Design Parameters, such as wall thickness, component clearance, drill slenderness ratio
 - Manifold Material library
 - Drill Diameters library
 - X-Drill Standard Library
2. Click **Save**.


The image shows a software dialog box titled "QuickManifolds : Submit Design". On the left side, there is a vertical navigation pane with four tabs: "Geometry", "Design", "Constraints", and "Submit". The "Design" tab is currently selected. The main area of the dialog is divided into several sections:

- Design Unit:** Contains two radio buttons: "inch" (unselected) and "mm" (selected). To the right of the "mm" button is the text "Go to QuickManifolds.com to change your design unit."
- Mounting:** Contains three radio buttons: "None" (selected), "Threaded Bolt Hole" (unselected), and "Thru. Hole" (unselected). To the right is a "Mounting Face" dropdown menu with "Bottom" selected.
- Design Parameters:** Contains three input fields: "Wall Thickness" with the value "5", "Component Clearance" with the value "1", and "Drill Slenderness Ratio" with the value "24".
- Manifold Material:** A dropdown menu showing "Dura-Bar Ductile Iron - Metric".
- Drill Diameters:** A dropdown menu showing "ANSI Metric Drills".
- X-Drill Standard:** A dropdown menu showing "SAE Plug Ports".
- At the bottom, there are two buttons: "Advanced Options" and "Save".


QuickManifolds Submit Design- Design

3. Click **Advanced Options** to set the following:


External Ports:




External Valves:



Cross-pilot:



Misc:




Constraints Tab


1. Define the Face constraints of the **Ports** and **Valves** in two different sections.
2. Independently set the face constraints for **Cartridge Valves** and **Surface Mounted Valves** in the Valves section.
3. Click **Save** button to save the QuickManifolds® data to the schematic.

Note:

To set the Advanced Constraints, click the **Advanced Options** button.



QuickManifolds : Submit Design
Constraints (Ports)



QuickManifolds :Submit Design
Constraints (Valves)

Advanced Constraints

The Advanced Constraints allow you to set constraints for external ports and valves.

Note


Advanced constraints are available only to External Ports and Valves that are constrained to a single face.

Specify Location


1. Select **External Port/Valves** from the External Port list or the Valves list.
2. Specify the **X-Distance** and **Y-Distance** of the selected port from the origin.
You can see the preview of the selected cavity and its location.
3. Click **Save**.

Aligning

1. Select **External Port/Valves** from the the External Port list or the Valves list.
2. Select the External Port/Valve name from the **Align with** drop down.
3. Select the **Horizontally** or **Vertically** option, per requirement
6. *You can see the preview of the selected cavities and their orientation.*
4. Click **Save**.



QuickManifolds : Advanced Constraints



QuickManifolds : Advanced Constraints

Submit Tab

1. Define Title Block Information such as, Title, Customer, Part No. Drawn, Checked by, Approved, and Projection Type.

It also displays the block design cost, account balance, and the available credit.

2. Click **Export** to save the QuickManifolds® Schematic data in the XML format.
3. Click **Save** to save the QuickManifolds® data to the schematic.
4. Click **Submit** to submit the design to QuickManifolds®.
A message displays to state the current block design cost.
5. Click **OK** to continue.
When the circuit is successfully submitted to QuickManifolds.com, the Submit Circuit message displays.
6. Click **OK**.

The screenshot shows the 'QuickManifolds : Submit Design' dialog box. It has a vertical sidebar on the left with four tabs: 'Geometry', 'Design', 'Constraints', and 'Submit'. The 'Design' tab is selected. The main area is titled 'Title Block Information' and contains the following fields:


- Title: Sample Schematic
- Customer: VEST, Inc.
- Part No: 3402
- Drawn: QM
- Checked: QM
- Approved: QM
- Projection Type: First Angle, Third Angle

At the bottom of the dialog are three buttons: 'Export', 'Save', and 'Submit'.

QuickManifolds Submit Design- Submit



Block Design Cost




Successful Circuit Submission

61. Checking Design Status

Check the status of the manifold design submitted to QuickManifolds®.

1. Click **Check Design Status** from the Submit option on the HyDraw® V700 ribbon menu.


The QuickManifolds: Login dialog box displays.



Submit: Check Design Status

2. Enter your user name and password.

The QuickManifolds: Check Design Status dialog box displays.



QuickManifolds: Login

3. Provide the Design Jobs detail, such as Created by, Created period, Part number, and Customer.

4. Click **GO**.

The submitted designs are enlisted in the Job Detail grid.

5. Select the design from the **Job Detail** section.

6. Click **View Job Details**.

*The **Refresh** button repopulates the job detail and status from the QuickManifolds® server.*

The Revision Details grid displays the design details.

*The **Revise Input** button enables resubmitting the design with constraints change at a very reduced cost i.e only 20% cost of the initial design.*

7. The **Download Files** section provides,

- Input file in the XML format
- MDTools® Viewer file
- Design Report in the PDF format
- Drawings of the design in step format

QuickManifolds : Check Design Status

Design Jobs

Created by: Me My company

Created: Last 15 jobs This month Last month This year All

Part Number (Full or Partial)

Customer (Full or Partial)

Job Detail

Part No	Description	Customer	Submit Date	User Name	Status
ST668006	ST668006		6/20/2014 1:28:00 AM	molon@innlievo.it	✓
ST005006-00	ST005006-00	MARCO VEZZANI	6/19/2014 8:30:00 PM	molon@innlievo.it	✓
ST005009-00	ST005009-00	MARCO VEZZANI	6/19/2014 7:46:00 PM	molon@innlievo.it	✓
ST005008-00	ST005008-00	MARCO VEZZANI	6/19/2014 7:43:00 PM	molon@innlievo.it	✓
ST005006-00	ST005006-00	MARCO VEZZANI	6/19/2014 7:42:00 PM	molon@innlievo.it	✓
Test_GS2	Test9	VestND	6/19/2014 11:08:00 AM	gopal.awasthi@vestusa.com	✓
Test_GS2	Test9	VestND	6/18/2014 9:45:00 AM	gopal.awasthi@vestusa.com	✓
1	PARKER	PARKER	6/17/2014 3:27:00 PM	molon@innlievo.it	✓
Test_GS1	Test9	VestND	6/17/2014 1:01:00 PM	gopal.awasthi@vestusa.com	✓

Revision Details of Job : ST005006-00 - ST005006-00

Cartridge Valves	Surface Mounted Valves	Threaded Ports	Flanges	Orifice Plugs	Mounting Holes
6	0	5	2	1	4,Tapped

Rev No	Revision Description	Status	Block Size: L x H x W (Volume)	No of X-Drills	User Comment
1	First Design	Completed	129x 181 x 158 (3689142)	7	


Download Files

[Input](#) [Viewer / MDTools](#) [Design Report](#) [Drawings](#)

QuickManifolds : Check Design Status

62. QuickManifolds Viewer

1. Click the **Viewer/MDTools** download link.
The QuickManifolds: Download File dialog box displays.




QuickManifolds: Download File

2. Select **Save File** or **Open File**.
3. Select **OK**.

Note

- To view the output files, install QuickManifolds® Viewer available along with the HyDraw® Installation.
- To get further details on working with QuickManifolds and downloading of the QuickManifolds User Manual, please visit www.QuickManifolds.com.



QuickManifolds Viewer opens the Design Output


63. Purging QuickManifolds Data

Remove the QuickManifolds® information from components in the schematic drawing.


1. Click **Purge**  on the QuickManifolds section of the HyDraw® V700 ribbon menu.
The Purge QuickManifolds Data warning message box displays and warns that the QuickManifolds data will be removed permanently.
2. Click **OK**, if you want to continue.
On completion, prompts a message – QuickManifolds data removed successfully.
3. Click **OK**.

CAUTION

Save the schematic with a different file name and/or location before removing QuickManifolds® information, for your convenience and future reference.



Purge QuickManifolds Data warning message box



Purge QuickManifolds Data message box

Migrating Drawings

AutoCAD Mechanical 2010 Test.dwg

64 Saving As DWG

Demo Schematic

ITEM ID	PORT SIZE	DE SRIPTION
A, T	G 1 1/2 -11	1-1/2 BSP
B, F	G 1 1/4 -11	1-1/4 BSP
DR, G	G 1/4-19	1/4 BSP

ITEM ID	QTY	MODEL CODE	DE SRIPTION	MANUFACTURER
0A1	1	6.00JJ-2HLRF48A-30.00	Cylinder Hydraulic	Parker
0A3	1	R-12-3	Reservoir	Custom Design
0M1	1	M3715	Electric Motor	Baldor
0P1	1	PE06R00B6B20PA00N	Pump Variable Single	Parker
0V1	1	6MV414	Needle Valve	Parker
0V2	1	SPRE510P15N	Check Valve	Parker
0V3	1	D81VHW004C1NJW	Direction Control Valve	Parker
0V4	1	BRC6MH	Counterbalance Valve	Parker
0Z2	1	MM1	Envelope	Custom Design Components
0Z4	1	G300	Pressure Gauge	Stauff
0Z7	1	D225M/SAEB	Motor/Pump Adapter	BSF
0Z8	1	400-M60-BB	Coupling Set	Magnaly

Model / Layout1

Regenerating model.
Command: <Coords off>
Command:

1:35:17 4/28/2010


STRUCT

MODEL

The Fill option is switched off by default in AutoCAD.

Switch the Fill option to ON in AutoCAD to display the filled regions in the drawing.

1. If AutoCAD is open, then insert the drawing exported from HyDraw®.
2. Enter **FILL** at the AutoCAD command prompt and press **Enter**.
3. Enter **ON** and press **Enter**.




The Schematic saved in DWG format

Regenerate the drawing to display filled regions.

1. Enter **REGEN** at the AutoCAD command prompt and press **Enter**.
2. **Save** and close the drawing.

Known Limitations:


- The exported drawing appears in black.
- Envelope line below an external port symbol is not automatically trimmed.
- If you have created symbols by importing an AutoCAD drawing, then the filled regions (e.g arrow heads) created using polyline or solid hatch in AutoCAD will appear unfilled in the exported drawing.
- Text background in the Visio drawing cannot be converted to DWG.



The Schematic displaying filled regions in the drawing file

Calculator

65 Unit Converter



65. Unit Converter

Convert the value of any unit category from one selected unit to another selected unit.

1. Click **Unit Converter** from the Calculator option on the HyDraw® V700 ribbon menu.

The Unit Converter dialog box displays.

2. Select a unit category.
3. Select the units system in **From** and **To** Unit list box, per requirement.
4. Specify the unit value in **From** Value text box.

The converted units value appears in the **To** Value text box, in the required unit system.


5. Click  to copy the **To** value to the clipboard.



Unit
Converter

Calculator

HyDraw Unit Converter



Unit Converter

Installation & Setup

HyDraw V700

HyDraw® V700

VEST

- 66 HyDraw V700 Installation
- 67 Submitting Authorization Request
- 68 Authorizing HyDraw V700
- 69 Transferring Standalone License
- 70 Using and Borrowing Network License
- 71 Library Network Configuration
- 72 Setup Online Services (FPT & QM)
- 73 Configure ERPServicesConfiguration.xml

Readme User Manual What's New Install on this computer Exit

66. HyDraw V700 Installation

The HyDraw® installation program installs HyDraw V700 on your computer system.

System Requirements


- Windows® 7 / 8 / 8.1
- Microsoft® .NET Framework version 4.0 or higher
- Adobe Reader 6.0 or higher
- Microsoft Visio® 2010 (32/64 bit)/ Microsoft Visio 2013 (32/64 bit) SP1
- Microsoft Excel 2007 or higher*
- Other system requirements, per Visio®

* Required only for exporting HyDraw Data from Visio and importing data into HyDraw Library

Software Installation

1. Insert the HyDraw® V700 DVD into the DVD drive.
If Auto Run is not set, then:
 - On the Start menu, click **Run**.
 - Browse to the HyDrawV700Start.exe program on the DVD drive.
 - Select **HyDrawV700Start.exe**, and click **Open**.
 - Click **OK**.
The HyDraw V700 startup screen displays.
 - Click **Install on this computer**.
The HyDraw V700 Installshield Wizard dialog displays.
The installation program starts and guides you through the installation process.
2. Install **HyDraw Library Manager** to install the Library and its manager.
The installation program starts and guides you through the installation process.
3. Install latest **QuickManifolds® Viewer** from the following link:-
<http://www.vestusa.com/download/QuickManifoldsViewerSetup.zip>
4. View the HyDraw V700 Read Me and User Manual from the provided links, if required.
5. Once complete, click **Exit** in HyDraw V700 dialog box and restart your computer for the changes to take effect.
HyDraw V700 and HyDraw Library Manager are installed on the system and HyDraw V700 is displayed in the Windows Start > Program menu.

A HyDraw V700 shortcut icon is created on the desktop.




HyDraw V700 startup screen




HyDraw V700 desktop icon

67. Submitting Authorization Request


1. Double click the **HyDraw® V700** desktop icon.
The HyDraw V700 Authorization dialog box displays.



4. Select **Authorize HyDraw V700** or **Try HyDraw V700** for 30 days trial period.
5. Click **Next**.




5. Select **Generate activation request**.
6. Click **Next**.




7. Enter the **Serial Number** provided when you purchased the software.
8. Click **Next**.

2. Alternatively select,
Start
> All Programs
> VEST
> HyDraw V700
> **HyDraw License Manager**
The HyDraw License Manager dialog box displays.



3. Click the **Activate** button.

The HyDraw V700 Authorization dialog box displays.



9. Enter your contact details.
10. Click **Create Request**

Authorization request is generated and prompts to save in an xml file.



11. Attach the request file to an email and send it to support@VESTusa.com.
12. Click **Close**.

68. Authorizing HyDraw V700

1. Double click the **HyDraw® V700** desktop icon.
If the program has not yet been authorized, the License Server Product Authorization dialog box displays.




2. Select **Authorize HyDraw V700**.
3. Click **Next**.


Alternatively select,
Start

- > All Programs
 - > VEST
 - > HyDraw V700
 - > **HyDraw License Manager**
- The HyDraw License Manager dialog box displays.*

4. Click the **Activate** button.
The HyDraw V700 Authorization dialog box displays.




5. Select **Open authorization file**.
6. Click **Next**.



7. Click **Browse** and select the saved Authorization Code xml file.
8. Click **Activate**.



9. Click **Close**.
The dialog box closes and HyDraw License is successfully activated.
10. Check the **License Details** from the HyDraw License Manager.




69. Transferring Standalone License

- The fully activated Network License has the **Transfer** button available to return the software to VEST for deactivation of the software on the current machine and reactivate it on a different machine.

Submit Transfer Request


- Select,
Start
> All Programs
> VEST
> HyDraw V700
> **HyDraw License Manager**

The HyDraw License Manager dialog box displays.



2. Click the **Transfer** button.

The HyDraw V700 Authorization dialog box displays.



3. Select **Generate transfer request**.
4. Click **Next**.



6. Change your contact details, if required.
7. Click **Create Request**.

A warning message appears indicating the license will be disabled.



8. Click **Yes** to continue or **No** to skip the transfer.

Authorization request is generated and prompts to save the xml file.




9. Attach the request file to an email and send it to support@VESTusa.com.
10. Click **Close**.

Note: The transfer process will be completed only, when you activate the authorization file received from VEST.

Authorize Transfer Request


1. Select, Start
> All Programs
> VEST
> HyDraw V700
> **HyDraw License Manager**

The HyDraw License Manager dialog box displays.




2. Click the **Transfer** button.

The HyDraw V700 Authorization dialog box displays.



4. Select **Open authorization file**.
5. Click **Next**.



6. Browse and select the saved Authorization Code .xml file.
7. Click **Activate**.



8. Click **Close**.

The dialog box closes and HyDraw License is successfully transferred.


70. Using and Borrowing Network License

The HyDraw client machines can use a network license available from the HyDraw License server Manager.

Using Network License

1. Select, Start
> All Programs
> VEST
> HyDraw V700
> HyDraw License Manager


The HyDraw License Manager dialog box displays.



3. 2. Select the **Network license** option.
4. 3. Set the License Server Name/IP Address and Port number.
5. 4. Click **Apply**.

Borrowing Network License

6. 1. Select the **License Borrowing** tab.



7. Select the **Borrow until** date.
8. Click the **Borrow** button.

The Borrowed license details are displayed in the grid.

9. 4. Click **OK** to exit.


Return Network License

1. The license can be returned by clicking the **Return** button.
2. Click **OK** to exit.

71. Library Network Configuration

HyDraw® V700 can access data from a HyDraw library on a local network by using the Corporate Library option. This enables all designers in an organization to work efficiently by sharing a common data resource. For details on installing the HyDraw Library, refer the Library Manager User Manual.

1. Click the **Library Path** tab.
The Library Path tab page displays.
2. Select the **Local Library** option.
3. Select the **Enable modification** check box to modify library.
4. Click **Browse...** and navigate to the folder where the HyDraw® Library data is stored.
The Symbols and Sub-subsystems path are automatically set if the Data, Symbols and Sub-systems folders are located at the same path.
5. Repeat the above steps for each of the specified HyDraw library path, if required.
6. Select the **Corporate Library** option to configure the second library path of your common Network library and repeat steps 3 to 6, if required.
7. Click **OK**.
All the HyDraw library paths are configured.



Data Path tab page

Note


All data paths shown are default.
You can configure to common network data paths.

72. Setup Online Services (FPT & QM)

Internet Settings for accessing FluidPowerTools.com and QuickManifolds.com

1. Automatically detect settings

If your computer is connected to the Internet through a direct LAN connection, then select the **Automatically detect settings** option.



The screenshot shows the 'HyDraw Options' dialog box with the 'Connection' tab selected. The 'Internet Settings' section is active, showing the 'Automatically detect settings' radio button selected. Below it are fields for 'Address' and 'Port'. The 'Enable authentication' checkbox is unchecked, with 'User Name' and 'Password' fields below it. A note at the bottom states: 'Note: You must restart Visio for settings to take effect.' The 'OK' and 'Cancel' buttons are at the bottom right.

Application	Units	Balloon	Connection	External Port	Parts List	Ports List
Library Path	Misc.	Internet Settings	QuickManifolds	ERP Settings		

Configuration

Automatically detect settings

Use proxy server

Address Port

Enable authentication

User Name Password

Note: You must restart Visio for settings to take effect.

OK Cancel


Connection Settings – Direct Connection

2 Configure LAN Settings

1. Open Internet Explorer.
2. Select Tools
> **Internet Options**
3. Select **LAN settings** from the Connections tab.
4. Configure the LAN settings.

Note

For direct connection, you should deselect the *Use a proxy server for your LAN* option in the LAN Settings dialog box.



IE browser settings

3 Proxy Connection

If your computer is connected to the Internet through a web proxy server, then select **Use proxy server**.


Configure the proxy settings.

1. Enter the Address.
2. Enter the Port number.
3. Enter authentication details, if required.


You may refer to the settings that may be already defined in your web browser.

Note

- If an automatic configuration script is used in the browser for proxy, then use the Proxy server settings from the LAN Settings dialog box in the browser to configure your Proxy Connection Settings.
- If you do not find proxy server details in the browser, then contact your system administrator.



Connection Settings – Proxy Settings



Internet Options

73. Configure ERPServiceConfiguration.xml

You can configure the XML Code for each property in **ERPServiceConfiguration.xml**.

The sample **ERPServiceConfiguration.xml** file is available at the "ERP" folder in the HyDraw Setup.

Configure the column name of the XML code for each property, per your ERP data Excel Sheet & InternalName and DisplayName in Properties table of ComponentData.mdb database by default available at "C:\VEST\HyDraw Library 2013\Data".

Each property has three attributes

1. **ColumnName** is the corresponding column as defined in the Excel sheet without any spaces. (Configurable)
2. **InternalName** is the variable name as in Properties table without any spaces. (Not Configurable)
3. **DisplayName** is the variable name as in Properties table. (Not Configurable)

Note:

ERPServiceConfiguration.xml and the ERP Excel sheet must be at the same location.

All the columns in the ERP Data in Excel, must be in Text Format.

Special characters are not supported in ERPServiceConfiguration.xml

```
<?xml version="1.0" encoding="UTF-8"?>
- <ERPPropertiesList SearchUsingPartNumber="False" Password="" ModelCodeOrPartNoColumn="SAPMaterialCode" DataSheetName="ERPData"
  xmlns:xsd="http://www.w3.org/2001/XMLSchema">
  - <ERPProperties>
    <ERPProperty ColumnName="Manufacturer" InternalName="Manufacturer" DisplayName="Manufacturer"/>
    <ERPProperty ColumnName="SAPMaterialCode" InternalName="SAPMaterialCode" DisplayName="SAPMaterialCode"/>
    <ERPProperty ColumnName="Price" InternalName="ListPrice" DisplayName="Price"/>
    <ERPProperty ColumnName="AssemblyCost" InternalName="AssemblyCost" DisplayName="Assembly Cost"/>
    <ERPProperty ColumnName="Stock" InternalName="Stock" DisplayName="Stock"/>
  - </ERPProperties>
</ERPPropertiesList>
```

Property	InternalName	DisplayName
134	List Price	Price
211	MalfunctionFlow	Malfunction Flow
131	Manufacturer	Manufacturer
162	MaxCurrent	Current Max
273	MaxSpeed	Speed Max
294	MaxWaterFlow	Water Flow Max
320	MicronRating	Micron Rating
127	ModelCode	Model Code
163	MotorFeet	Feet
135	NominalSize	Nominal Size
299	NumberOfBolts	No. of Bolts

	ModelCode	Manufacturer	Price	AssemblyCost	Stock	SAPMaterialCode
1	SV4-10-C-0-00-00	Eaton	29	5	50	9000000001
2	SV4-10-3-0-00-00	Eaton	33	4	45	9000000002
3	PFR2-10-C-3B-0-1-00	Eaton	29	5	12	9000000003
4	NV1-10-K-0-3B-00	Eaton	32	6	56	9000000004

ERPServiceConfiguration.xml, Properties Table & Sample ERP Data in Excel Format

A

- Accessories, 66
- Advanced Constraints, 127
- Aligning Symbol Ports, 80
- Aligning Symbols, 77
- Aligning System Port Names, 81
- Application, 14
- Authorization, 142
- Authorizing HyDraw V700, 143
- Automatically detect settings, 148

B

- Balloon, 17

C

- CAD Files, 70
- Changing Text Height, 85
- Checking Design Status, 129
- Collating CAD Files, 112
- Collating Documents, 111
- Collating Files, 110
- Configure External Port, 36
- Configure LAN Settings, 149
- Connecting Lines, Ports, and Symbols, 56
- Connection, 18
- Constraining/Unconstraining Symbols, 90
- Constraints Tab, 126
- Copying Properties, 72
- Creating and Inserting Net List, 101

- Creating and Inserting Parts List, 95
- Creating and Inserting Ports List, 99
- Creating and Inserting Solenoid Actuation Chart, 102

D

- Design Requirements, 63
- Design Tab, 124
- Display Format, 109
- Display Settings, 105
- Dock HyDraw Property Manager, 12
- Document, 70

E

- Editing in Place, 83
- Editing Port Name, 82
- Editing Solenoid Information, 84
- Envelope Line, 24
- ERP Interface, 75
- Exporting To MDTools, 116
- External Port, 19
- External Ports, 71

F

- Fetch from Library, 64
- Fetch Port from Library, 35
- Fetching Pipe and Tube Data from Library, 58
- Flipping Symbols, 79

G

- Geometry Tab, 121
- Go To QuickManifolds.com, 119

H

- HyDraw Library Explorer, 8
- HyDraw Options, 14
- HyDraw Property Manager, 11
- HyDraw Startup, 6
- HyDrawV700 Ribbon Menu, 7

I

- Insert Ports List, 99
- Inserting Connection, 55
- Inserting Connection Point, 61
- Inserting Envelope, 53
- Inserting External Port, 33
- Inserting from DC Valve Configurators, 50
- Inserting from Parts List, 48
- Inserting Gauge Port, 37
- Inserting Interruption Point, 60
- Inserting Symbol, 31
- Inserting Symbols from Parts List, 48
- Inserting Terminators, 59
- Installation, 140
- Installation & Setup, 139
- Internet Settings, 27
- Introduction, 2
- Introduction to QuickManifolds, 118

L

Library Network Configuration, 147
Library Path, 22
Load on startup, 24

M

Manifold Quote, 114
MDTools Interface, 115
Migrating Drawings, 133
Misc., 23
Model Data, 64
Modifying Symbols, 76

O

Online Services, 148

P

Parts List, 20, 94
Ports List, 21
Proxy Connections, 150
Purging Price Data, 106
Purging Properties, 107
Purging QuickManifolds Data, 132

Q

Quick Manifolds® Viewer, 131
QuickManifolds, 28, 29

R

Reassigning Item ID, 92
Refreshing Properties, 73
Relocating Symbol, 89
Rotating Property Text, 86
Rotating Symbols, 78

S

Saving As DWG, 134
Searching Components, 38
Searching Sub-systems, 44
Selected Item, 12
Selected Item Properties, 63
Showing/Hiding Port Names, 104
Software Installation, 141
Solenoid Naming, 26
Stacking Symbols, 91
Submit Tab, 128
Submitting Circuit to QuickManifolds, 120
Support, 4
Symbol, 63

Symbol Color, 25
System, 12
System Properties, 71
System Requirements, 140

T

Text Size, 23
Transferring License, 144

U

Units, 15
Unlocking Position, 87
Unlocking Size, 88
Updating Balloons, 93
Updating Property List, 74
User Manuals, 4
Using and Borrowing Network License, 146

W

Workspace, 5

Circuit Design

HyDraw®

Manifold Design

MDTools®

FLUID
POWER
TOOLS!

QUICK
MANIFOLDS!

Services



VEST, Inc..
3250 W. Big Beaver Road, Suite 440,
Troy, MI 48084 USA.

Call: +1 (248) 649-9550
Email: sales@VESTusa.com
Visit: VESTusa.com

© 2014, VEST, Inc.
All rights reserved.